

## FRIO- head cooling system for Concerto and Orchestra

Unscrew the 4 screws and the accessory will be open in two parts.

Apply the two parts on the head of the machine and tight the screws to hold the accessory in place.

The blue tubes provide can now be applied.

Blue tube need to be positioned on the bottom of FRIO.

See the picture:



1-FRIO can be connected to the water supply with one tube-enter and one tube-exit. The cold water circulating in the system will cool the head during the extrusion.

OR

2-FRIO can be connect with  
LF02300065 FRIO R Water re-circulation  
The pump will recirculate the water in  
FRIO (we advise to use a water tank  
with some ice) without connection at the  
water supply.