



FRYCLONE™



#2590ILTEST

OIL TEST KIT

INSTRUCTIONS

Oil must be cooled before testing.



STEP 1

ALLOW YOUR FRYER OIL TO COOL COMPLETELY.

Deje que el aceite de su freidora se enfríe por completo.

STEP 2

PLACE OIL FROM YOUR FRYER IN THE OIL DROPPER.

Extraiga aceite de la freidora con el gotero.

STEP 3

PLACE THE OIL DROPPER BACK INTO ITS HOLDER NEXT TO THE COLOR TUBE.

Coloque el gotero con aceite de regreso en su base al lado del tubo de muestra.

STEP 4

COMPARE THE FRYER OIL TO THE COLOR TUBE.

Compare el color del aceite de la freidora con el tubo de muestra.

STEP 5

WHEN FRYER OIL COLOR MATCHES THE COLOR TUBE OR IS DARKER, DISCARD OIL.

Cuando el color del aceite de la freidora coincida con el color del tubo de muestra o sea más oscuro, deseche el aceite.

STEP 6

KEEP THE DROPPER IN THE HOLDER BETWEEN USE.

Mantenga el gotero en su base después de cada uso.



**SCAN TO
LEARN MORE**

about our oil
management
products.