


Grease Guardian D Series—Daily Maintenance




Daily Maintenance, 1-2 times daily


Attention: Do not use sinks when accessing unit to do maintenance




Unfasten and remove the main tank lid. Lift the strainer basket upwards and allow surplus water to drain back into tank




Dispose the contents into a food waste bin. Before replacing strainer rinse the basket mesh under a hot Tap.




Unclip oil container by lifting it up and outward from the bracket




Unscrew oil container cap and pour skimmed oil contents into a dedicated waste oil drum. Replace oil container




Lift wiper blade upwards from its axle support



Rinse sediment from wiper blade And replace blade inside tank



Ensure the grease channel inside tank is free from any grease deposits. Use a bottle brush to clean along channel length



At end of day fill a connected sink with warm water and release to flush through Grease Guardian, to remove silt and prevent odours.