

BREWING



STEP 1

Begin each brew cycle with a clean, empty funnel and server. Insert a BUNN® filter into the funnel.



STEP 2

Pour a packet of fresh coffee into the filter. Level the bed of grounds by gently shaking. Slide the loaded brew funnel into the funnel rails until it stops.



STEP 3

Make sure the ENABLE BREW switch is ON. Press the switch of the desired batch size. Press the Brew Switch (A, B, or C) assigned to the desired product/recipe.



STEP 4

When coffee no longer drips from the funnel tip, carefully remove the brew funnel and discard the used grounds. Press the ENABLE BREW switch to OFF to prevent a false start. Thoroughly clean and sanitize the brew funnel and funnel tip screen.



STEP 5

Fresh coffee is available at the faucet. Drain the server before starting another brew cycle.

CLEANING



STEP 1

Empty server. Unscrew the faucet cap from the faucet body and disassemble all faucet parts.



STEP 2

Clean and sanitize all faucet components. Use a bristle brush (BOM #00674.0000) to thoroughly scrub the faucet body.




STEP 3

Clean the interior of server and the lid assembly. Reassemble all parts.



STEP 4

Unscrew the sprayhead.



STEP 5

Remove the gasket to separate the two halves. Clean and sanitize all parts. Verify all the holes are open.

CLEANING



STEP 6

To reassemble sprayhead, align the dimples as shown.



STEP 7

Install gasket around the assembled sprayhead. Reinstall sprayhead on brewer.



STEP 8

Wipe the sprayhead panel clean with a damp cloth.



STEP 9

Wipe down the entire outside surface of the brewer with a clean damp cloth.