



INDUSTRIAL *Series*

USER SAFETY



WARNING — To prevent personal injury.

- **WARNING — CHILD SUPERVISION**
 - Unsupervised children may misuse the product, leading to potential injury or damage to the product.
 - Children should be supervised to ensure that they do not play with the product.
 - Do not allow children to use the product without proper supervision.
- **Chair and Stool Safety:** Keep all four legs on the ground. Do not shake or sway. Do not stand on the chair or stool.
- **Prevent Misuse:** Do not use chairs or stools as support when leaning or standing.
- **Do Not Use if Damaged:** Product should not be used if damage is found. Contact customer service.
- **Safety Labels:** Never remove any safety labels attached to the product.

INITIAL SETUP

- **Inspect the Packaging:** Examine the product's packaging for any signs of damage that may have occurred during shipping.
- **Unboxing:** Open the packaging with care.
 - Do not press a box cutter or knife through packaging, as it may damage the product or accessories.
 - Ensure you do not damage the product or its components when removing it from the packaging.
 - If any damage is present, contact customer service immediately.
- **Check Components:** Examine welds and fasteners for damage before use. Ensure all legs sit flat on the ground.

CLEANING & MAINTENANCE

GENERAL CLEANING

- **Clean with Mild Soap:** Clean with mild soap and a damp cloth. Wipe down with a dry, clean cloth.
- **Avoid Harsh Pads or Cleaners:** Avoid abrasive materials (scrubber pads, steel wool, etc.) or harsh cleaners (ammonia, bleach, acetone, glass cleaners, etc.).
- **Test Cleaners:** Test new cleaners on a hidden area before use. Always use a cleaner that is marked safe for the material being cleaned.
- **Follow Warranty Guidelines:** Damage from misuse or improper cleaning may not be covered under warranty.

WOODEN SEATS

- **Hardware Check:** Inspect the hardware daily to ensure all fasteners remain secure and that the back does not move, shift, or loosen during use.
- **Ensure Wood is Fully Dry:** Allow wood to dry completely after cleaning before use to prevent damage.

Side Barstool

ASSEMBLY INSTRUCTIONS




LANCASTER™
TABLE & SEATING

INDUSTRIAL *Series*


HARDWARE & PARTS

HARDWARE

A (4) ¼" x 30 mm
Hex Screws



B (4) ¼"
Washers




C 4 mm
Allen Key




PARTS LIST

D Back Section



E Stool Frame



ASSEMBLY

1. Stool Placement:

Place the stool frame (E) upside down on the edge of a stable, level surface such as a table or counter.

2. Locate Back Section:

Position the back section (D) against the bottom of the stool frame (E), aligning all mounting holes.

3. Insert Hardware:

Insert the provided screws (A) and washers (B) through the holes in the back section (D) and into the corresponding holes in the stool frame (E).

4. Tighten Screws:

Hand-tighten all screws (A) clockwise until the back section (D) is securely held in place. Then, fully tighten all screws using the 4 mm Allen key (C).

5. Verify Assembly:

Confirm all screws are fully tightened and both sections are securely fastened together. Verify that the back does not move, shift, wobble, or become misaligned.

