


Winch Components



Mounting head components



Cross arm components


CRADLE UNIT

Part	Description
01-00	Complete cradle assembly
01-02	Pull pin with fasteners
01-03	Complete cross arm assembly
01-04	Cross arm body
01-05	Support hook with fasteners
01-06	End caps (set of 8)
01-07	Outrigger with end caps
01-17	Complete mounting head assembly
01-18	Complete spring yoke pin assembly
01-20	Cradle Body

FRAME UNIT

Description

<u>ı aı</u> ı	Description
52-00	Complete frame assembly with winch &
	Telescoping Sections 439
52-01	Frame housing
52-02	"G" section w/ #35 chain assembly
52-03	#35 chain assembly
52-04	"H" section w/ #40 chain assembly
52-05	#40 chain assembly
52-06	"I" section w/ #50 chain assembly
52-07	#50 chain assembly
52-08	Coupler nut assembly
52-09	11/4" #50 roller assembly



Drive Assembly



FRAME UNIT continued

Part	Description	
52-10	Outer plate set w/ bronze bearings	
52-11	Drive assembly	
52-12	1/2" X 21/4" Shoulder Bolt w/ Fasteners	
52-13	Winch mount w/ fasteners	
52-14	Retaining hook w/ fasteners	
52-15	Clutch assembly w/ sprocket	
52-16	#40 winch drive chain	
52-17	Drive chain quard	

WINCH UNIT

<u>Part</u>	Description
53-00	Complete 439 winch assembly
53-01	Winch wheel with bronze flange bearings
53-02	Brake hub with bolts
03-03	7/8" bushing
03-04	1/2" bolt with washer and nut
03-05	Complete brake arm assembly
03-07	Tension spring "B"
03-08	Brake handle cover
03-10	Winch handle

TRIPOD BASE UNIT

02 27 (02 01
Description
Tripod base assembly w/ 6" Casters
Center Leg
Outer Leg w/ Fasteners
6" Caster w/ Fasteners
Backstop tip (Pack of 6)
Tie arm with fasteners
Backstop Fiber Washer w/ Fasteners
Slide Yoke Pin Clip w/ Fasteners