

TAYLOR. DIGITAL TIMER 5873

BATTERY INFORMATION:

The timer operates on 2 AA batteries (included). Before use, remove the strip under battery cover. Replace batteries when readings grow dim.

SET THE CLOCK:

1. Slide the switch on the bottom of the timer to CLOCK SET.
2. Press "H" to set the hour (1-11 AM/PM or 24 hour mode). Press "M" to set minutes the "▶■" to confirm time setting.
3. Slide switch back to CLOCK or TIMER.

PROGRAM THE TIMER:

1. Slide switch to **TIMER**.
2. Press "H" and "M" to set hours and minutes.
3. Press "▶■" to start the timer countdown.
4. To pause, press "▶■". Press to start timing again.
5. To reset the timer, press "▶■" to pause then press again and hold for 3 seconds.
6. When the countdown reaches zero, the alarm will sound at 95 decibels. Press any button to stop the alarm. The timer has a memory function and will display the previously set time.
7. The timer will also count up. Press "▶■" when '00:00 00' displays and the timer will count up and "▲ **TIMER**" shows on the LCD.
8. If the slide switch is in CLOCK or CLOCK SET and the countdown reaches zero, the alarm

will sound and **TIMER DONE** will blink. Press any button to stop the alarm. The count up time will display when the switch is moved to **TIMER**. Press "▶■" to recall memory function. Press and hold "▶■" for 3 seconds to reset.

9. The maximum timer allowance is '**23H 59M 00S**'.

NOTE: Please recycle or dispose of batteries per local regulations.

WARNING: Batteries may pose a choking hazard. As with all small items, do not let children handle batteries. If swallowed, seek medical attention immediately.

PRECAUTION: Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the scale will not be used for a long period of time.

CLEANING & CARE:

Clean by hand. Do not completely immerse timer in water or put into dishwasher.

ONE YEAR LIMITED WARRANTY:

Taylor warrants this product to be free from defects in material or workmanship (excluding batteries), and on return, will repair or replace it at our option, without charge.

©2019 Taylor, a division of Lifetime Brands Inc.
All rights reserved.

www.taylorusa.com

Made in China.

5873 6.19WC