


- A: Turn handle until edge of label is 2mm above strip plate
- B: Position guide marker directly over the gap between labels

7



- A: Place your bottle on the rollers and rotate handle to apply label
- B: Stop turning when guide marker is over gap in next label

Need more help? Download the full manual or contact us

LAB01



Start Start


4270 Airborn Dr, Addison, TX 75001, USA 972.248.1999 | tech@startinternational.com

STARTinternational.com


LAB01


Manual Label Applicator

ITEMS INCLUDED




Dispenser






Core Holder (2) Reel Guide (2)




A: Install handle onto feed roller

B. Install and tighten the thumb screws




- A: Place bottle onto rollers and adjust screws with hex wrench to position rollers until bottle rests 1 2mm above strip plate
- B: Tighten screws on both sides and remove your bottle



A: Slide reel guide onto the hanger bar

B: Insert core holders into your label roll and slide loaded roll onto reel hanger bar

C: Slide other reel guide onto the hanger bar



A: Position label roll for desired placement and tighten thumb screws

B: Feed label liner under guide bar and brush

В