




LED Write-On Board

Use and Care Guide

08/2026



Hazard Statement

WARNING—COMPONENT REPLACEMENT

Non-original parts may compromise safety systems, leading to increased risk of fire or system failure.

Component parts shall be replaced with like components.

Servicing must be performed by factory authorized service personnel to minimize the risk of ignition due to incorrect parts or improper service.

Initial Setup

Inspect the Packaging: Check for shipping damage before unboxing. Do not use the unit if damage is present.

Unboxing: Remove packaging carefully. Avoid using sharp tools that could damage the unit.

- Do not force a box cutter or knife through packaging, as it may damage the product or accessories.
- Ensure you do not damage the product or its components when removing it from the packaging.
- If any damage is present, contact customer service immediately.

Box Contents:

- LED Board
- Barrel Cord
- Microfiber Cleaning Cloth
- Hanging Chain
- Remote
- Power Connector

Clean Before First Use: Clean the write-on board with a wet cloth and dry thoroughly with a dry cloth before first-time use.


LED Write-On Board

Use and Care Guide



Installation

Mounting: If this board is to be installed on a wall, please use the mounting points found on the top and sides of the unit. Additionally, make sure that the hardware is the correct type for the mount surface type.



Operation

Write Messages: Write on the board using a suitable erasable marker only (sold separately).

Change Messages: When changing the message on the board, wipe with a wet cloth and dry the board with the included cleaning cloth.

Cleaning

Routine Cleaning: Wipe the board with a wet cloth and dry with the included microfiber cleaning cloth.

Wire Unit: Connect the barrel connector to the one side of the power connector. Connect the other side to the board using the attached USB-B male connector. Make sure it powers on and the remote is sending commands to the board.

