


# Leveling Feet for Outdoor Trash Can

## ASSEMBLY INSTRUCTIONS




**LANCASTER™**  
TABLE & SEATING


### PARTS LIST:



(A) Can Body  
1 Pc



(B) Leveling feet  
4 Pcs




(C) Hex Nuts  
8 Pcs

### TOOLS REQUIRED:

- Adjustable wrench (not supplied; optional)


### STEP 1

Using your hand or a wrench, turn one hex nut clockwise until it is affixed to a leveling foot.



### STEP 2

Insert the leveling foot through the bottom of the bracket in the trash can frame so that the screw is facing up. Add the remaining hex nut to the screw and turn in a clockwise direction until tightened. Adjusting the tightness of the two hex nuts will move the leveling foot to the desired height.



### STEP 3

Repeat these steps on the remaining 3 leveling feet.

