

## **WHEEL LIFT INSTALLATION**

READ THESE INSTRUCTIONS COMPLETELY BEFORE YOU START. IF YOU DON'T UNDERSTAND THESE INSTRUCTIONS, PLEASE CALL OUR CUSTOMER EXPERIENCE TEAM AT 800-453-1192 FOR ASSISTANCE. YOUR SAFETY IS VERY IMPORTANT TO US.

Procedure for installing the wheel lift on Little Giant Ladder Systems Aerial Safety Cage ladders.


- 1. Failure to comply with all instructions may result in serious injury.
- 2. Make sure this kit is compatible with your Cage. Before installing this kit, identify all kit components. If any components are missing, damaged or if you have any questions concerning the use of this kit on Little Giant Ladder Systems products, please contact our Customer Experience Team at 800-453-1192. Do not substitute any components.
- 3. Inspect the Cage before installing this kit. Repair or replace any damaged or missing Cage parts before using the Cage. Use only Little Giant Ladder Systems repair or replacement parts. If you are unable to repair it, discard the Cage.




NOTE: IF ANY OTHER PART OF THE CAGE IS DAMAGED BEFORE OR DURING THE PROCESS OF INSTALLING AND/OR REPAIRING, PLEASE CONTACT OUR CUSTOMER EXPERIENCE TEAM FOR ASSISTANCE AT 800-453-1192. **DO NOT USE A DAMAGED CAGE!** 



1. Identify the 4 areas that you will be installing the wheel assemblies.




2. Make sure when you are lining up the two Wheel Lifts for installation that the two angle arms are facing towards each other. (As shown in the illustration).




3. Make sure that the angle arms are angled towards the climbing side or outside of the ladder. (As shown in the illustration).



4. Insert the Wheel Lifts onto the bottom rung, and line up the holes.




5. Insert 4 hex head screws into the bottom rung, through the Wheels Lifts and cap with lock nuts.




6. Tighten with (2) 7/16" wrenches.




7. Repeat steps 3-6 on adjacent side of the bottom rung.




8. Line up the tube step and insert it making sure that it fits in-between the angle arms of the wheel lifts.



9. Insert the cap screw through the lock washer, angle arm and into the tube step. (As shown in the illustration).



10. Using a 7/16" wrench, tighten the cap screw into place.



11. Repeat steps 9-10 on opposite side of the tube step.




12. Repeat steps 2-11 on opposite outer assembly.



13. Make sure the ladder is completely stable before use.

## How-To Cage: Wheel Lift







1. Place your hands on either side of the Cage to stabilize yourself.



2. Place your (right or left) foot on the Wheel Lift bar (yellow) and push down.



3. Once the Wheel Lift wheels are engaged, move to the other side of the ladder and repeat steps 1 and 2. The Cage will be able to move freely now.



4. To disengage the Wheel Lift, place the toe end of your foot under the (yellow) Wheel Lift and pull up.

## WARNING

NEVER ALLOW WHEELS TO CONTACT ANY SURFACE WHILE THE CAGE IS BEING CLIMBED, USED OR ADJUSTED. DO NOT MOVE WITH ANYONE ON ANY PART OF THE CAGE; THE CAGE MAY ROLL OUT AND CAUSE INJURY. WHEELS MUST ONLY BE USED TO ASSIST IN TRANSPORTING THE CAGE.