

# Use & Care Guide



LANCASTER<sup>™</sup>  
TABLE & SEATING

## OUTDOOR ADIRONDACK FURNITURE



### ASSEMBLY/ARRIVAL

- It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
- Inspect all welds and fasteners on chairs/tables for damage before use. Ensure all legs are straight and touching the floor.
- Assembly, if applicable, should be done by a qualified adult using the applicable instructions.



### CAUTION

- Do not use furniture if any parts are broken or missing. This includes screws, fasteners, and feet/glide.
- Always follow cleaning and maintenance instructions.
- Do not stand on chairs, side tables, or footrests.
- Children should always be supervised by an adult whenever they are using this furniture. Do not shake or sway while in use. Keep all four legs on the ground when in use.
- Do not let anyone sit, stand, lean, jump, or climb on side tables or footrest.



### STORAGE

- If storing, make sure that furniture is completely dry before putting in storage.
- None of these items are stackable.



### MAINTENANCE

- **Monthly:** Ensure the structure is sound and there are no cracks or breaks in the material.
- Tighten all bolts and screws. Do not over-tighten, as this may damage the material.



### CLEANING INSTRUCTIONS

#### HIGH IMPACT POLYSTYRENE

- Clean with a soft cloth moistened with a neutral detergent.
- Avoid harsh chemicals.

