

Full Height Bun Pan Rack

Assembly Instructions

TOOLS REQUIRED

Adjustable Wrench or
10mm and 14mm Socket

PARTS:

- (A) (2) Pan Slide Frames
- (B) (6) Crossbars
 - (4) Top/Mid (Long)
 - (2) Bottom (Short)
- (C) (4) 5" Casters
- (D) (8) U Brackets
- (E) (12) Bolts
 - (8) 10mm (Top/Mid)
 - (4) 14mm (Bottom)



NEED HELP?

Scan here to follow
along with the full
assembly video:



Assembly Instructions

1. Insert (2) Long Crossbars into the top holes of the Pan Slide Frames.
2. Attach U Brackets (2 for each Crossbar) and to the outside of the Pan Slide Frames using the 10mm Bolts. Hand-tighten the bolts* and repeat the process for the other side.
3. Repeat steps 1 & 2 for the (2) Middle Crossbars.
4. Insert the (4) Casters** into the bottom of the Frames. The locking casters should be installed in the same end of the rack so they can easily be set.
5. Once the casters are properly aligned, the remaining (2) Short Crossbars can be installed on the bottom of the rack using the 14mm Bolts.***
6. Put a bun pan in both the top and bottom of the rack to ensure your bun pan is square.
7. Tighten each bolt with a wrench. Your bun pan rack is now ready to use.

NOTES

* Be sure to not over-tighten the bolts, or you may damage the Frame and/or Crossbars.

** Make sure the hole in the caster post is aligned with the hole in the collar.

*** The bottom Crossbars do not require U Brackets. They can be bolted on directly though the hole in the collar.

