


HALF HEIGHT BUN PAN RACK

ASSEMBLY INSTRUCTIONS

TOOLS NEEDED: An Adjustable Wrench OR 10mm and 14mm Socket are required for assembly.



INCLUDED PARTS

- A (2) Pan Slide Frames
- B (4) Crossbars
 - (2) Top (Long)
 - (2) Bottom (Short)
- C (4) 5" Casters
- (4) U Brackets
- E (8) Bolts
 - (4) 10mm (Top)
 - (4) 14mm (Bottom)

FINAL PRODUCT



Need Help?

Scan here to follow along with the full assembly video!



06/2022

ASSEMBLING THE PAN RACK

Insert the (2) Long Crossbars into the top holes of the Pan Slide Frames.



Attach U Brackets (2 for each Crossbar) and to the outside of the Pan Slide Frames using the 10mm Bolts. Hand-tighten the bolts* and repeat the process for the other side.



Insert the (4) Casters** into the bottom of the Frames. The locking casters should be installed in the same end of the rack so they can easily be set.



Once the casters are properly aligned, the remaining (2) Short Crossbars can be installed on the bottom of the rack using the 14mm Bolts.***



Put a bun pan in both the top and bottom of the rack to ensure your bun pan is square.



Tighten each bolt with a wrench. Your bun pan rack is now ready to use.



- * NOTE: Be sure to not over-tighten the bolts, or you may damage the Frame and/or Crossbars.
- NOTE: Make sure the hole in the caster post is aligned with the hole in the collar.
- *** NOTE: The bottom Crossbars do not require U Brackets, they can be bolted on directly though the hole in the collar.