

193VOA36B, 193VOA48B, 193VOA60B, 193VOA70B

Vertical Open Air Merchandisers

- The following applies to units equipped with a condensation overflow container.
- When operating outside ideal conditions, the overflow pan may fill multiple times per day, resulting in water on the floor and requiring the container to be emptied.
- Following the steps below will ensure the merchandiser operates correctly.

- **Installation Conditions:**

If the overflow tank fills frequently, confirm the unit is indoors in a climate-controlled area (75°F and <55% relative humidity).

- **Condenser Filter:**

Pull the lower grille out and down. Check and clean the mesh filter and the condenser fins behind it regularly.

- **Airflow Restriction:**

Do not place products or materials on or against the bottom pan louvers.

- **Cooling Issues:**

A dirty mesh filter or condenser fins can reduce cooling performance and damage refrigeration components.

- **Water Leaks:**

Check the condensation overflow tank regularly and empty it as needed.

- **External Airflow:**

Ensure heating vents, AC units, or other airflow sources are not blowing into the product cavity.

- **Night Curtain:**

During closed hours, pull down the clear plastic night curtain to reduce refrigeration cycling and condensation buildup.

- **Contact Service:**

If problems persist, contact a licensed and insured food service technician to have the unit professionally inspected and serviced.

