# Parts Manual

## Commercial
# Gas Ranges



351S24(L/N), 351S36(L/N), 351S60(L/N), 351S36G24(L/N), 351S60G24(L/N), 351S60GS24(L/N), 351S36G12(L/N), 351S36SU(L/N), 351S36G36(L/N), 351S60G36(L/N), 351S60G48(L/N), 351C36(L/N)

**REVISED 01/2025**

# Parts Manual

## Contents


Safety Precautions . . . . . 3
Gas Pressure . . . . . 3

**351S24(L/N)**

Range Main Body Parts List & Diagram . . . . . 4–5
Gas Control Assembly Parts List & Diagram . . . . . 6
Oven Tank Assembly Parts List & Diagram . . . . . 7

**351S36(L/N)**

Range Main Body Parts List & Diagram . . . . . 8-9
Gas Control Assembly Parts List & Diagram . . . . . 10
Oven Tank Assembly Parts List & Diagram . . . . . 11

**351S60(L/N)**

Range Main Body Parts List & Diagram . . . . . 12–13
Gas Control Assembly Parts List & Diagram . . . . . 14
Oven Tank Assembly Parts List & Diagram . . . . . 15

**351S36G12(L/N)**

Body Parts List & Diagram . . . . . 16-17
Oven Tank Assembly Parts List & Diagram . . . . . 18

**351S36G24(L/N)**

Body Parts List & Diagram . . . . . 19-20
Oven Tank Assembly Parts List & Diagram . . . . . 21
Oven Door Assembly Parts List & Diagram . . . . . 22

**351S36G36(L/N)**

Range Main Body Parts List & Diagram . . . . . 23-24
Gas Control Assembly Parts List & Diagram . . . . . 25
Oven Tank Assembly Parts List & Diagram . . . . . 26

**351S60G24(L/N)**

Range Main Body Parts List & Diagram . . . . . 27-28
Gas Control Assembly Parts List & Diagram . . . . . 29
Oven Tank Assembly Parts List & Diagram . . . . . 30

**351S60G36(L/N)**

Range Main Body Parts List & Diagram . . . . . 31-32
Gas Control Assembly Parts List & Diagram . . . . . 33
Oven Tank Assembly Parts List & Diagram . . . . . 34

**351S60G48(L/N)**

Range Main Body Parts List & Diagram . . . . . 35-36
Gas Control Assembly Parts List & Diagram . . . . . 37
Oven Tank Assembly Parts List & Diagram . . . . . 38


Intertek 4003027

Conforms to ANSI STD Z83.11b-2009 (R2011)
Conforms to CSA STD 1.8b-2009 (R2011) NSF
Tested by ETL

# Parts Manual

**351S60GS24(L/N)**

Range Main Body Parts List & Diagram ..... 39-40
Gas Control Assembly Parts List & Diagram ..... 41
Oven Tank Assembly Parts List & Diagram ..... 42

**351S36SU(L/N)**

Range Main Body Parts List & Diagram ..... 43-44
Gas Control Assembly Parts List & Diagram ..... 45
Oven Tank Assembly Parts List & Diagram ..... 46

**351C36(L/N)**

Range Main Body Parts List & Diagram ..... 47-48
Gas Control Assembly Parts List & Diagram ..... 49
Oven Tank Assembly Parts List & Diagram ..... 50

Wiring Diagram ..... 51

# Safety Precautions

## CAUTION:

- Failure to comply with the following operation instructions could lead to potential hazards and/or unsafe practice and could result in injury and damage to product and property.

## NOTICE:

- Local codes regarding installation vary greatly from one area to another. The National Fire Protection Association, Inc., states in its NFPA96 latest edition that Local codes are “Authority Having Jurisdiction” when it comes to requirement for installation of equipment. Therefore, installation should comply with all Local codes.
- This product is intended for commercial use only. Not for residential use.

## WARNING:

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other equipment.
- Improper installation, adjustment, alteration, service or maintenance could lead to property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing CPG equipment. This manual must be retained for future reference.
- A factory authorized agent must handle all maintenance and repair.

# Gas Pressure

- The appliance and its individual shutoff valve (to be supplied by user) must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of ½ PSI (3.45 kPa).
- The appliance must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than ½ PSI (3.45 kPa).


## 351S24(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 1 | Inner Flue Assembly |
| 4 | - | 2 | Slide Rail |
| 5 | - | 1 | Right Side Panel |
| 6 | 351228058007 | 1 | Crumb Tray - 19" x 26" |
| 7 | 351302090149 | 4 | Adjustable Leg with Plate |
| 8 | 351302130384 | 1 | Oven Burner |
| 9a | 35128051088 | 1 | Oven Pilot - NAT |
| 9b | 351302130447 | 1 | Oven Pilot - LP |
| 10 | 351302170058 | 1 | Thermocouple |
| 11a | 351302150198 | 1 | #36 Burner Orifice - NAT |
| 11b | 351302150190 | 1 | #51 Burner Orifice - LP |
| 12 | - | 1 | Orifice Elbow |
| 13a | 351302190428 | 1 | Door Hinge - Right |
| 13b | 351302190430 | 1 | Door Hinge - Left |
| 14 | - | 1 | 24" Kick Plate |
| 15 | - | 1 | Oven Door Assembly |
| 16 | 351302070220 | 1 | Door Handle |
| 17 | - | 1 | Oven Tank Assembly |
| 18 | - | 1 | Left Side Panel |
| 19 | 351301130111 | 1 | Oven Knob |
| 20 | 351202230111 | 4 | Stove Knob |
| 21 | - | 1 | Front Panel |
| 22 | 351302220064 | 1 | Oven Thermostat Valve |
| 23 | 351228046045 | 2 | Range Pilot Pipe (Short) |
| 24 | 351228046016 | 2 | Range Pilot Pipe (Long) |
| 25 | 351302130019 | 4 | Range Pilot |
| 26 | 351128051028 | 2 | Burner Assembly (Short) |
| 27 | 351128051027 | 2 | Burner Assembly (Long) |
| 28 | 351302250132 | 4 | Burner Grate |

## 351S24(L/N)


## RANGE MAIN BODY



## 351S24(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150198 | 4 | #36 Burner Orifice - NAT |
| 1b | 351302150189 | 4 | #50 Burner Orifice - LP |
| 2 | 351302050051 | 4 | Gas Stove Valve |
| 3 | 351302220027 | 2 | Dual Pilot Valve |
| 4 | - | 1 | Screw |
| 5 | 351302220064 | 1 | Oven Thermostat Valve |
| 6 | - | 1 | Gas Inlet Pipe |



## 351S24(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | 351302110504 | 2 | Rack Holder |
| 8 | - | 1 | Oven Tank Lower Front Plate |
| 9 | - | 1 | Baseboard |
| 10 | - | 1 | Deflector/baffle |
| 11 | 351302110557 | 2 | Rack 20" x 24.5" |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S36(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 1 | Inner Flue Assembly |
| 4 | - | 2 | Slide Rail |
| 5 | - | 1 | Right Side Panel |
| 6 | 351228051012 | 1 | Crumb Tray - 31" x 32" |
| 7 | 351302090149 | 4 | Adjustable Leg with Plate |
| 8 | 351302130384 | 1 | Oven Burner |
| 9a | 35128051088 | 1 | Oven Pilot - NAT |
| 9b | 351302130447 | 1 | Oven Pilot - LP |
| 10 | 351302170058 | 1 | Thermocouple |
| 11a | 351302150198 | 1 | #36 Burner Orifice - NAT |
| 11b | 351302150190 | 1 | #51 Burner Orifice - LP |
| 12 | - | 1 | Orifice Elbow |
| 13a | 351302190428 | 1 | Door Hinge - Right |
| 13b | 351302190430 | 1 | Door Hinge - Left |
| 14 | - | 1 | 32" Kick Plate |
| 15 | - | 1 | Oven Door Assembly |
| 16 | 351302070144 | 1 | Door Handle |
| 17 | - | 1 | Oven Tank Assembly |
| 18 | - | 1 | Left Side Panel |
| 19 | 351301130111 | 1 | Oven Knob |
| 20 | 351202230111 | 6 | Stove Knob |
| 21 | - | 1 | Front Panel |
| 22 | 351302220064 | 1 | Oven Thermostat Valve |
| 23 | 351228046045 | 3 | Range Pilot Pipe (Short) |
| 24 | 351228046016 | 3 | Range Pilot Pipe (Long) |
| 25 | 351302130019 | 6 | Range Pilot |
| 26 | 351128051028 | 3 | Burner Assembly (Short) |
| 27 | 351128051027 | 3 | Burner Assembly (Long) |
| 28 | 351302250132 | 6 | Burner Grate |

## 351S36(L/N)


## RANGE MAIN BODY



## 351S36(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150198 | 6 | #36 Burner Orifice - NAT |
| 1b | 351302150189 | 6 | #50 Burner Orifice - LP |
| 2 | 351302050051 | 6 | Gas Stove Valve |
| 3 | 351302220027 | 3 | Dual Pilot Valve |
| 4 | 351302220064 | 1 | Oven Thermostat Valve |
| 5 | - | 1 | Screw |
| 6 | - | 1 | Gas Inlet Pipe |



## 351S36(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110503 | 2 | Rack 26" x 24.5" |
| 9 | - | 1 | Baseboard |
| 10 | 35128051028 | 1 | Deflector/baffle |
| 11 | 351302110504 | 2 | Rack Holder |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S60(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back panel Assembly |
| 2 | 35128051040 | 3 | Back Panel Support |
| 3 | - | 2 | Inner Flue Assembly |
| 4 | - | 3 | Slide Rail |
| 5 | - | 1 | Right Side Panel |
| 6 | 351228051012 | 2 | Crumb Tray 31" x 32" |
| 7 | - | 2 | Oven Tank Assembly |
| 8 | 351302090149 | 6 | Adjustable leg with Plate |
| 9 | 351302130384 | 2 | Oven Burner |
| 10 | 351302170058 | 2 | Thermocouple |
| 11a | 351302130447 | 2 | Oven Pilot - LP |
| 11b | 35128051088 | 2 | Oven Pilot - NAT |
| 12a | 351302150198 | 2 | #36 Burner Orifice - NAT |
| 12b | 351302150190 | 2 | #51 Burner Orifice - LP |
| 13 | - | 2 | Orifice Elbow |
| 14a | 351302190428 | 2 | Door Hinge - Right |
| 14b | 351302190430 | 2 | Door Hinge - Left |
| 15 | - | 2 | 30" Kick Plate |
| 16 | - | 2 | Oven Door Assembly |
| 17 | 351302070144 | 2 | Door Handle |
| 18 | - | 1 | Left Side Panel |
| 19 | 351301130111 | 2 | Oven Knob |
| 20 | 351202230111 | 10 | Stove Knob |
| 21 | - | 1 | Front Control Panel |
| 22 | 351302050051 | 2 | Gas Stove Valve |
| 23a | 351228046045 | 5 | Range Pilot Pipe (Short) |
| 23b | 351228046016 | 5 | Range Pilot Pipe (Long) |
| 24 | 351302130019 | 10 | Stove Pilot |
| 25 | 351128051028 | 5 | Burner Assembly (short) |
| 26 | 351128051027 | 5 | Burner Assembly (long) |
| 27 | 351302250132 | 10 | Burner Grate |

## 351S60(L/N)


## RANGE MAIN BODY



## 351S60(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150198 | 10 | #36 Burner Orifice - NAT |
| 1b | 351302150189 | 10 | #50 Burner Orifice - LP |
| 2 | 351302050051 | 10 | Gas Stove Valve |
| 3 | 351302220027 | 5 | Dual Pilot Valve |
| 4 | 351302220064 | 2 | Oven Thermostat Valve |
| 5 | - | 1 | Gas Inlet Pipe |



## 351S60(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110504 | 2 | Rack Holder |
| 9 | 351302110503 | 2 | Rack 26" x 24.5" |
| 10 | - | 1 | Baseboard |
| 11 | 35128051028 | 1 | Deflector/baffle |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S36G12(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 1 | Inner Flue Assembly |
| 4 | - | 1 | Slide Rail |
| 5 | - | 1 | Griddle Plate Assembly |
| 6 | 351302130387 | 1 | Giddle Burner |
| 7 | 35128078006 | 1 | Grease Tray |
| 8 | - | 1 | 32" Kickplate |
| 9 | 351302090149 | 4 | Adjustable leg with Plate |
| 10 | 351302130384 | 1 | Oven Burner |
| 11 | 351302170058 | 1 | Thermocouple |
| 12a | 35128051088 | 1 | Oven Pilot - NAT |
| 12b | 351302130447 | 1 | Oven Pilot - LP |
| 13a | 351302150198 | 1 | #36 Burner Orifice - NAT |
| 13b | 351302150190 | 1 | #51 Burner Orifice - LP |
| 14 | - | 1 | Orifice Elbow |
| 15a | 351302190428 | 1 | Door Hinge - Right |
| 15b | 351302190430 | 1 | Door Hinge - Left |
| 16 | - | 1 | Oven Door Assembly |
| 17 | 351302070144 | 1 | Door Handle |
| 18 | - | 1 | Oven Tank Assembly |
| 19 | 351228058007 | 1 | Crumb Tray 19" x 26" |
| 20 | 351301130111 | 1 | Oven Knob |
| 21 | 351202230111 | 5 | Stove/Griddle Knob |
| 22 | - | 1 | Front Control Panel |
| 23 | 351228046045 | 2 | Range Pilot Pipe (Short) |
| 24 | 351228046016 | 2 | Range Pilot Pipe (Long) |
| 25 | 351302130019 | 4 | Stove Pilot |
| 26 | 351302050051 | 5 | Gas Stove/Griddle Valve |
| 27a | 351302150197 | 1 | #44 Griddle Burner Orifice - NAT |
| 27b | 351302150193 | 1 | #54 Griddle Burner Orifice - LP |
| 28a | 351302150198 | 4 | #36 Stove Burner Orifice - NAT |
| 28b | 351302150189 | 4 | #50 Stove Burner Orifice - LP |
| 29 | 351302220064 | 1 | Oven Thermostat Valve |
| 30 | 351302220027 | 2 | Dual Pilot Valve |
| 31 | 351128051028 | 2 | Burner Assembly (short) |
| 32 | 351128051027 | 2 | Burner Assembly (long) |
| 33 | 351302250132 | 4 | Burner Grate |

## 351S36G12(L/N)


## RANGE MAIN BODY



## 351S36G12(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110503 | 2 | Rack 26" x 24.5" |
| 9 | - | 1 | Baseboard |
| 10 | 35128051028 | 1 | Deflector/baffle |
| 11 | 351302110504 | 2 | Rack Holder |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S36G24(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 1 | Griddle Plate Assembly |
| 4 | - | 1 | Inner Flue Assembly |
| 5 | - | 1 | Slide Rail |
| 6 | 351302130387 | 2 | Giddle Burner |
| 7 | - | 1 | Right Side Panel |
| 8 | 351228077016 | 1 | Crumb Tray 19" x 7" |
| 9 | 35128078006 | 1 | Grease Tray |
| 10 | - | 1 | Oven Tank Assembly |
| 11 | 351302090149 | 4 | Adjustable leg with Plate |
| 12 | 351302130384 | 1 | Oven Burner |
| 13 | 351302170058 | 1 | Thermocouple |
| 14a | 35128051088 | 1 | Oven Pilot - NAT |
| 14b | 351302130447 | 1 | Oven Pilot - LP |
| 15a | 351302150198 | 1 | #36 Burner Orifice - NAT |
| 15b | 351302150190 | 1 | #51 Burner Orifice - LP |
| 16 | - | 1 | Orifice Elbow |
| 17a | 351302190428 | 1 | Door Hinge - Right |
| 17b | 351302190430 | 1 | Door Hinge - Left |
| 18 | - | 1 | 32" Kickplate |
| 19 | - | 1 | Oven Door Assembly |
| 20 | 351302070144 | 1 | Door Handle |
| 21 | 351301130111 | 1 | Oven Knob |
| 22 | 351202230111 | 4 | Stove/Griddle Knob |
| 23 | - | 1 | Front Control Panel |
| 24 | - | 1 | Gas Control Assembly |
| 25 | - | 1 | Crumb Tray |
| 26 | - | 1 | Left Side Panel |
| 27 | 351228046045 | 1 | Range Pilot Pipe (Short) |
| 28 | 351228046016 | 1 | Range Pilot Pipe (Long) |
| 29 | 351302130019 | 2 | Stove Pilot |
| 30 | 351128051028 | 1 | Burner Assembly (short) |
| 31 | 351128051027 | 1 | Burner Assembly (long) |
| 32 | 351302250132 | 2 | Burner Grate |

## 351S36G24(L/N)


## RANGE MAIN BODY



## 351S36G24(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150198 | 2 | #36 Stove Burner Orifice - NAT |
| 1b | 351302150189 | 2 | #50 Stove Burner Orifice - LP |
| 2 | 351302050051 | 4 | Gas Stove/Griddle Valve |
| 3 | 351302220027 | 1 | Dual Pilot Valve |
| 4a | 351302150197 | 2 | #44 Griddle Burner Orifice - NAT |
| 4b | 351302150193 | 2 | #54 Griddle Burner Orifice - LP |
| 5 | 351302220028 | 2 | Pilot Valve |
| 6 | 351302220064 | 1 | Oven Thermostat Valve |
| 7 | - | 1 | Gas Inlet Pipe |



## 351S36G24(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110503 | 2 | Rack 26" x 24.5" |
| 9 | - | 1 | Baseboard |
| 10 | 35128051028 | 1 | Deflector/baffle |
| 11 | 351302110504 | 2 | Rack Holder |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S36G36(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 1 | Inner Flue Assembly |
| 4 | - | 1 | Slide Rail |
| 5 | - | 1 | Griddle Assembly |
| 6 | 351302130387 | 3 | Giddle Burner |
| 7 | - | 1 | Crumb Tray |
| 8 | - | 1 | Right Side Panel |
| 9 | - | 1 | Oven Tank Assembly |
| 10 | 351302090149 | 4 | Adjustable leg with Plate |
| 11 | 351302130384 | 1 | Oven Burner |
| 12 | 351302170058 | 1 | Thermocouple |
| 13a | 35128051088 | 1 | Oven Pilot - NAT |
| 13b | 351302130447 | 1 | Oven Pilot - LP |
| 14a | 351302150198 | 1 | #36 Burner Orifice - NAT |
| 14b | 351302150190 | 1 | #51 Burner Orifice - LP |
| 15 | - | 1 | Orifice Elbow |
| 16a | 351302190428 | 1 | Door Hinge - Right |
| 16b | 351302190430 | 1 | Door Hinge - Left |
| 17 | - | 1 | Oven Door Assembly |
| 18 | 351302070144 | 1 | Door Handle |
| 19 | 351301130111 | 1 | Oven Knob |
| 20 | 351202230111 | 3 | Stove/Griddle Knob |
| 21 | - | 1 | Front Panel |
| 22 | - | 1 | Left Side Panel |
| 23 | - | 1 | Gas Control Assembly |

## 351S36G36(L/N)


## RANGE MAIN BODY



## 351S36G36(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150197 | 3 | #44 Griddle Burner Orifice - NAT |
| 1b | 351302150193 | 3 | #54 Griddle Burner Orifice - LP |
| 2 | 351302050051 | 3 | Gas Valve |
| 3 | 351302220028 | 3 | Pilot Valve |
| 4 | - | 1 | Screw |
| 5 | 351302220064 | 1 | Oven Thermostat Valve |
| 6 | - | 1 | Gas Inlet Pipe |



## 351S36G36(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | 351302110504 | 2 | Rack Holder |
| 8 | 351302110503 | 2 | Rack 26" x 24.5" |
| 9 | - | 1 | Oven Tank Lower Front Plate |
| 10 | - | 1 | Baseboard |
| 11 | 35128051028 | 1 | Deflector/baffle |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S60G24(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | 351302250132 | 6 | Burner Grate |
| 2 | 351128051028 | 3 | Burner Assembly (short) |
| 3 | 351128051027 | 3 | Burner Assembly (long) |
| 4 | - | 1 | Left Side Panel |
| 5 | - | 1 | Front Countertop |
| 6 | - | 1 | Front Control Panel |
| 7 | 351202230111 | 8 | Stove/Griddle Knob |
| 8 | 351301130111 | 2 | Oven Knob |
| 9 | - | 2 | Oven Door Assembly |
| 10 | 351228059011 | 2 | 30" Kickplate |
| 11 | 35128078006 | 1 | Grease Tray |
| 12 | 351302140137 | 2 | Orifice Elbow |
| 13a | 351302150198 | 2 | #36 Oven Burner Orifice - NAT |
| 13b | 351302150190 | 2 | #51 Oven Burner Orifice - LP |
| 14 | 351302170058 | 2 | Thermocouple |
| 15a | 35128051088 | 2 | Oven Pilot - NAT |
| 15b | 351302130447 | 2 | Oven Pilot - LP |
| 16 | 351302130384 | 2 | Oven Burner |
| 17/18 | 351302090149 | 6 | Adjustable Leg with Plate |
| 19 | - | 2 | Oven Tank Assembly |
| 20 | - | 1 | Right Side Panel |
| 21 | 351302130387 | 2 | Griddle Burner |
| 22 | - | 1 | Griddle Plate Assembly |
| 23 | - | 1 | Griddle Flue Part 2 |
| 24 | - | 1 | Griddle Flue Part 1 |
| 25 | - | 1 | Back Panel Assembly |
| 26 | 351228051012 | 1 | Crumb Tray 31" x 32" |
| 27 | 351228077016 | 1 | Crumb Tray 19" x 7" |
| 28 | 351302070144 | 2 | Door Handle |
| 29 | 351228046015 | 3 | Range Pilot Pipe (Short) |
| 30 | 351228046016 | 3 | Range Pilot Pipe (Long) |

## 351S60G24(L/N)


## RANGE MAIN BODY



## 351S60G24(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | 351302050051 | 8 | Gas Stove Valve |
| 2a | 351302150198 | 6 | #36 Stove Burner Orifice - NAT |
| 2b | 351302150189 | 6 | #50 Stove Burner Orifice - LP |
| 3 | - | 1 | Gas Inlet Pipe |
| 4 | 351302220027 | 3 | Dual Pilot Valve |
| 5 | 351302220064 | 2 | Oven Thermostat Valve |
| 6a | 351302150197 | 2 | #44 Griddle Burner Orifice - NAT |
| 6b | 351302150193 | 2 | #54 Griddle Burner Orifice - NAT |
| 7 | 351302220028 | 2 | Single Pilot Valve |



## 351S60G24(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110504 | 2 | Rack Holder |
| 9 | 351302110503 | 2 | Rack 26" x 24.5" |
| 10 | - | 1 | Baseboard |
| 11 | 35128051028 | 1 | Deflector/baffle |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S60G36(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 3 | Back Panel Support |
| 3 | - | 2 | Inner Flue Assembly |
| 4 | - | 3 | Slide Rail |
| 5 | - | 1 | Griddle Plate Assembly |
| 6 | 351302130387 | 3 | Giddle Burner |
| 7 | - | 1 | Grease Tray |
| 8 | - | 1 | Right Side Panel |
| 9 | - | 2 | Oven Tank Assembly |
| 10 | 351302090149 | 6 | Adjustable leg with Plate |
| 11 | 351302130384 | 2 | Oven Burner |
| 12 | 351302170058 | 2 | Thermocouple |
| 13a | 35128051088 | 2 | Oven Pilot - NAT |
| 13b | 351302130447 | 2 | Oven Pilot - LP |
| 14a | 351302150198 | 2 | #36 Burner Orifice - NAT |
| 14b | 351302150190 | 2 | #51 Burner Orifice - LP |
| 15 | - | 2 | Orifice Elbow |
| 16a | 351302190428 | 2 | Door Hinge - Right |
| 16b | 351302190430 | 2 | Door Hinge - Left |
| 17 | - | 2 | Oven Door Assembly |
| 18 | - | 2 | 30" Kickplate |
| 19 | 351302070144 | 2 | Door Handle |
| 20 | 351301130111 | 2 | Oven Knob |
| 21 | 351202230111 | 7 | Stove/Griddle Knob |
| 22 | - | 1 | Front Control Panel |
| 23a | 351228046045 | 2 | Range Pilot Pipe (Short) |
| 23b | 351228046016 | 2 | Range Pilot Pipe (Long) |
| 24 | 351302130019 | 6 | Stove Pilot |
| 25 | 351128051028 | 2 | Burner Assembly (short) |
| 26 | 351128051027 | 2 | Burner Assembly (long) |
| 27 | 351228058007 | 1 | Crumb Tray 19" x 26" |
| 28 | 351302250132 | 4 | Burner Grate |
| 29 | - | 1 | Gas Control Assembly |

## 351S60G36(L/N)


## RANGE MAIN BODY



## 351S60G36(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150198 | 4 | #36 Stove Burner Orifice - NAT |
| 1b | 351302150189 | 4 | #50 Stove Burner Orifice - LP |
| 2 | 351302050051 | 7 | Gas Stove Valve |
| 3 | 351302220027 | 2 | Dual Pilot Valve |
| 4 | 351302220064 | 2 | Oven Thermostat Valve |
| 5a | 351302150197 | 3 | #44 Griddle Burner Orifice - NAT |
| 5b | 351302150193 | 3 | #54 Griddle Burner Orifice - NAT |
| 6 | 351302220028 | 3 | Single Pilot Valve |
| 7 | - | 1 | Gas Inlet Pipe |



## 351S60G36(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110504 | 2 | Rack Holder |
| 9 | 351302110503 | 2 | Rack 26" x 24.5" |
| 10 | - | 1 | Baseboard |
| 11 | 35128051028 | 1 | Deflector/baffle |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S60G48(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 2 | Inner Flue Assembly |
| 4 | - | 2 | Slide Rail |
| 5 | - | 1 | Griddle Plate Assembly |
| 6 | 351302130387 | 4 | Giddle Burner |
| 7 | - | 1 | Crumb Tray |
| 8 | - | 2 | Oven Tank Assembly |
| 9 | 351302090149 | 6 | Adjustable leg with Plate |
| 10 | 351302130384 | 2 | Oven Burner |
| 11 | 351302170058 | 2 | Thermocouple |
| 12a | 35128051088 | 2 | Oven Pilot - NAT |
| 12b | 351302130447 | 2 | Oven Pilot - LP |
| 13a | 351302150198 | 2 | #36 Burner Orifice - NAT |
| 13b | 351302150190 | 2 | #51 Burner Orifice - LP |
| 14 | - | 2 | Orifice Elbow |
| 15a | 351302190428 | 2 | Door Hinge - Right |
| 15b | 351302190430 | 2 | Door Hinge - Left |
| 16 | - | 2 | 30" Kickplate |
| 17 | - | 2 | Oven Door Assembly |
| 18 | 351302070144 | 2 | Door Handle |
| 19 | 351301130111 | 2 | Oven Knob |
| 20 | 351202230111 | 6 | Stove/Griddle Knob |
| 21 | - | 1 | Front Control Panel |
| 22 | - | 1 | Crumb Tray |
| 23 | 351302250132 | 2 | Burner Grate |
| 24a | 351228046045 | 1 | Range Pilot Pipe (Short) |
| 24b | 351228046016 | 1 | Range Pilot Pipe (Long) |
| 25 | 351302130019 | 2 | Stove Pilot |
| 26 | 351128051028 | 1 | Burner Assembly (short) |
| 27 | 351128051027 | 1 | Burner Assembly (long) |
| 28 | - | 1 | Gas Control Assembly |

## 351S60G48(L/N)


## RANGE MAIN BODY



## 351S60G48(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150198 | 2 | #36 Stove Burner Orifice - NAT |
| 1b | 351302150189 | 2 | #50 Stove Burner Orifice - LP |
| 2 | 351302050051 | 6 | Gas Stove Valve |
| 3 | 351302220027 | 4 | Dual Pilot Valve |
| 4 | 351302220064 | 2 | Oven Thermostat Valve |
| 5a | 351302150197 | 4 | #44 Griddle Burner Orifice - NAT |
| 5b | 351302150193 | 4 | #54 Griddle Burner Orifice - NAT |
| 6 | 351302220028 | 4 | Single Pilot Valve |
| 7 | - | 1 | Gas Inlet Pipe |



## 351S60G48(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110504 | 2 | Rack Holder |
| 9 | 351302110503 | 2 | Rack 26" x 24.5" |
| 10 | - | 1 | Baseboard |
| 11 | 35128051028 | 1 | Deflector/baffle |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S60GS24(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back Panel Assembly |
| 2 | 35128051040 | 3 | Back Panel Support |
| 3 | - | 2 | Inner Flue Assembly |
| 4 | - | 3 | Slide Rail |
| 5 | - | 1 | Griddle Plate Assembly |
| 6 | - | 1 | Right Side Panel |
| 7 | 351302130384 | 3 | Giddle Burner |
| 8 | 351302110676 | 1 | Broiler Rack |
| 9 | 351228058007 | 1 | Crumb Tray 19" x 26" |
| 10 | 35128079008 | 1 | Grease Tray |
| 11 | - | 2 | Oven Tank Assembly |
| 12 | 351302090149 | 6 | Adjustable leg with Plate |
| 13 | 351302130384 | 2 | Oven Burner |
| 14 | 351302170058 | 2 | Thermocouple |
| 15a | 35128051088 | 2 | Oven Pilot - NAT |
| 15b | 351302130447 | 2 | Oven Pilot - LP |
| 16a | 351302150198 | 2 | #36 Burner Orifice - NAT |
| 16b | 351302150190 | 2 | #51 Burner Orifice - LP |
| 17 | - | 2 | Orifice Elbow |
| 18a | 351302190428 | 2 | Door Hinge - Right |
| 18b | 351302190430 | 2 | Door Hinge - Left |
| 19 | - | 2 | 30" Kickplate |
| 20 | - | 2 | Oven Door Assembly |
| 21 | 351302070144 | 2 | Door Handle |
| 22 | 351301130111 | 2 | Oven Knob |
| 23 | 351202230111 | 9 | Stove/Griddle Knob |
| 24 | - | 1 | Front Control Panel |
| 25 | 351228051012 | 1 | Crumb Tray 31" x 32" |
| 26 | - | 1 | Left Side Panel |
| 27 | - | 1 | Gas Control Assembly |
| 28a | 351228046045 | 3 | Range Pilot Pipe (Short) |
| 28b | 351228046016 | 3 | Range Pilot Pipe (Long) |
| 29 | 351302130019 | 6 | Stove Pilot |
| 30 | 351128051028 | 3 | Burner Assembly (short) |
| 31 | 351128051027 | 3 | Burner Assembly (long) |
| 32 | 351302250132 | 6 | Burner Grate |

## 351S60GS24(L/N)


## RANGE MAIN BODY



## 351S60GS24(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Gas Inlet Pipe |
| 2a | 351302150198 | 6 | #36 Stove Burner Orifice - NAT |
| 2b | 351302150189 | 6 | #50 Stove Burner Orifice - LP |
| 3 | 351302050051 | 9 | Gas Stove Valve |
| 4 | 351302220027 | 3 | Dual Pilot Valve |
| 5 | 351302220064 | 2 | Oven Thermostat Valve |
| 6 | 351302220028 | 3 | Single Pilot Valve |
| 7a | 351302150190 | 3 | #51 Griddle Burner Orifice - NAT |
| 7b | 351302150195 | 3 | #59 Griddle Burner Orifice - LP |



## 351S60GS24(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110504 | 2 | Rack Holder |
| 9 | 351302110503 | 2 | Rack 26" x 24.5" |
| 10 | - | 1 | Baseboard |
| 11 | 35128051028 | 1 | Deflector/baffle |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351S36SU(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 1 | Inner Flue Assembly |
| 4 | - | 2 | Slide Rail |
| 5 | - | 1 | Right Side Panel |
| 6 | - | 1 | Oven Tank Assembly |
| 7 | 351302090149 | 4 | Adjustable leg with Plate |
| 8a | 351302190428 | 1 | Door Hinge - Right |
| 8b | 351302190430 | 1 | Door Hinge - Left |
| 9 | 351302130384 | 1 | Oven Burner |
| 10 | 351302170058 | 1 | Thermocouple |
| 11a | 351302130447 | 1 | Oven Pilot - LP |
| 11b | 35128051088 | 1 | Oven Pilot - NAT |
| 12a | 351302150198 | 1 | #36 Burner Orifice - NAT |
| 12b | 351302150190 | 1 | #51 Burner Orifice - LP |
| 13 | - | 1 | Orifice Elbow |
| 14 | - | 1 | 32" Kick Plate |
| 15 | - | 1 | Oven Door Assembly |
| 16 | 351302070144 | 1 | Door Handle |
| 17 | 351228051012 | 1 | Crumb Tray 31" x 32" |
| 18 | - | 1 | Left Side Panel |
| 19 | 351301130111 | 1 | Oven Knob |
| 20 | 351202230111 | 6 | Stove Knob |
| 21 | - | 1 | Front Control Panel |
| 22 | 351302050051 | 6 | Gas Stove Valve |
| 23a | 351228046045 | 3 | Range Pilot Pipe (Short) |
| 23b | - | 3 | Range Pilot Pipe (Long) |
| 24 | 351302130019 | 6 | Stove Pilot |
| 25 | 351128051028 | 3 | Burner Assembly (short) |
| 26 | - | 3 | Burner Assembly (long) |
| 27 | 351302250132 | 6 | Burner Grate |
| 28b | 351228046016 | 3 | Range Pilot Pipe (Long) |
| 29 | 351302130019 | 6 | Stove Pilot |
| 30 | 351128051028 | 3 | Burner Assembly (short) |
| 31 | 351128051027 | 3 | Burner Assembly (long) |
| 32 | 351302250132 | 6 | Burner Grate |

## 351S36SU(L/N)


## RANGE MAIN BODY



## 351S36SU(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1a | 351302150198 | 6 | #36 Burner Orifice - NAT |
| 1b | 351302150189 | 6 | #50 Burner Orifice - LP |
| 2 | 351302050051 | 6 | Gas Stove Valve |
| 3 | 351302220027 | 3 | Dual Pilot Valve |
| 4 | 351302220064 | 1 | Oven Thermostat Valve |
| 5 | - | 1 | Screw |
| 6 | - | 1 | Gas Inlet Pipe |



## 351S36SU(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Rear Shrouding Assembly |
| 2 | - | 1 | Oven Tank Top Plate |
| 3 | - | 1 | Temp Probe Cover |
| 4 | - | 1 | Oven Tank Left Plate |
| 5 | - | 1 | Oven Tank Bottom Left Limit Plate |
| 6 | - | 2 | Oven Tank Side Reinforcement Plate |
| 7 | - | 1 | Oven Tank Lower Front Plate |
| 8 | 351302110503 | 2 | Rack 26" x 24.5" |
| 9 | - | 1 | Baseboard |
| 10 | 35128051028 | 1 | Deflector/baffle |
| 11 | 351302110504 | 2 | Rack Holder |
| 12 | 351302190429 | 2 | Door hinge - seat |
| 13 | - | 1 | Oven Tank Bottom Right Limit Plate |
| 14 | - | 1 | Oven Tank Right Plate |




## 351C36(L/N)

## RANGE MAIN BODY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | - | 1 | Back panel Assembly |
| 2 | 35128051040 | 2 | Back Panel Support |
| 3 | - | 1 | Inner Flue Assembly |
| 4 | - | 2 | Slide Rail |
| 5 | | 1 | Motor Assembly |
| 6 | - | 1 | Right Side Panel |
| 7 | - | 1 | Oven Tank Assembly |
| 8 | 351302090149 | 4 | Adjustable leg with Plate |
| 9 | 351302130387 | 1 | Oven Burner |
| 10 | 351302170065 | 1 | Thermocouple |
| 11a | 351302130447 | 1 | Oven Pilot - LP |
| 11b | 35128051088 | 1 | Oven Pilot - NAT |
| 12a | 351302150342 | 1 | #35 Burner Orifice - NAT |
| 12b | 351302150189 | 1 | #50 Burner Orifice - LP |
| 13 | - | 1 | Orifice Elbow |
| 14a | 351080175 | 1 | Door Switch |
| 14b | 35128092036 | 1 | Door Switch Bracket |
| 14b | 35128092037 | 1 | Door Switch Touch Plate |
| 15 | - | 1 | Kick Plate |
| 16 | 35128092006 | 1 | Oven Door Assembly |
| 17 | 351302070144 | 1 | Door Handle |
| 18 | 351302220135 | 1 | Oven Pilot Valve |
| 19 | - | 1 | Left Side Panel |
| 20 | 35128092016 | 1 | Motor Support Plate |

## 351C36(L/N)


## RANGE MAIN BODY



## 351C36(L/N)

## GAS CONTROL ASSEMBLY


| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | 351302250181 | 3 | Rear Burner Grate |
| 2 | 351302250132 | 3 | Front Burner Grate |
| 3 | 351128051027 | 3 | Burner Assembly (long) |
| 4 | 351128051028 | 3 | Burner Assembly (short) |
| 5 | 351228046045 | 3 | Range Pilot Pipe (Short) |
| 6 | 351228046016 | 3 | Range Pilot Pipe (Long) |
| 7 | 351302130019 | 6 | Stove Pilot |
| 8 | 35128092005 | 1 | Crumb Tray |
| 9 | 351301080174 | 1 | Oven Switch |
| 10 | 351301110555 | 1 | Oven Knob |
| 11 | 351202230111 | 6 | Stove Knob |
| 12 | - | 1 | Front Control Panel |
| 13a | 351302150198 | 6 | #36 Burner Orifice - NAT |
| 13b | 351302150189 | 6 | #50 Burner Orifice - LP |
| 14 | 351302050051 | 6 | Gas Stove Valve |
| 15 | 351302220027 | 3 | Dual Pilot Valve |
| 16 | 351302220132 | 1 | Oven Thermostat Valve |
| 17 | 351302202348 | 1 | Gas Valve Switch Socket |
| 18 | - | 1 | Gas Inlet Pipe |



## 351C36(L/N)

## OVEN TANK ASSEMBLY

| Key | Item Number | Qty | Description |
|---|---|---|---|
| 1 | 351314490021 | 1 | Temp Probe Cover |
| 2 | - | 1 | Fan cover |
| 3 | 351302190429 | 2 | Door hinge - seat |
| 4 | 351302110504 | 2 | Rack Holder |
| 5 | 351302110503 | 2 | Rack 26" x 24.5" |



# Wiring Diagram

