

Use & Care Guide

PLANTERS



ASSEMBLY / ARRIVAL

1. It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
2. Assembly, if applicable, should be conducted by a qualified adult using the applicable instructions.
3. Always follow cleaning and maintenance instructions.



CLEANING INSTRUCTIONS

1. Clean with mild soap or detergent and a clean, dry cloth. Recommended cleaners: Noble Lemon Lance (147LMNLANRQT) and Noble All Surf (147ALLSURF1G).
2. Make sure product is fully dry after cleaning and before use.



ONGOING MAINTENANCE

1. Inspect products for damage before use.
2. Follow cleaning instructions for applicable material.
3. Clean up bird droppings, mold, mildew, pollen, dirt, and dust as quickly as possible.



STORAGE

1. If applicable, follow product's instructions for maximum stacking quantity.
2. When storing outdoor furniture long term, cover or move to an enclosed area.

OPTIONAL DRAINAGE HOLES

Follow the instructions below to drill drainage holes into the bottom of the planter to allow excess water to drain out of the planter.

1. Use safety glasses while drilling.
2. Before filling your planter, turn planter upside down and place on a level, stable surface. Locate desired drainage hole location.
3. Drill at a slow speed to create a clean hole without cracking the plastic. Depending on your desired drain hole size and your plant, we recommend using a 1/4" to 1/2" drill bit. Start with a smaller bit if you're unsure, and gradually increase the size if necessary.



CAUTION

1. The planter is intended for use on a stable and level surface. Do not use if the product is not level.
2. Once planter is filled, handle with care.
3. Do not use if parts are broken or missing.
4. Always follow cleaning and maintenance instructions.
5. Requires adult supervision when children are present.

