

Wire Bun / Sheet Pan Racks




Assembly Instructions

TOOLS REQUIRED

Rubber Mallet and Towel





PARTS:

- (A) (2) Pan Slide Frames
- (B) (4) Post Ends
- (C) (2) Frames
- (D) (4) Casters
- (E) (8) Split Sleeves
- (F) (12) Crutch Tips






Assembly Instructions

1. Fully insert a caster into each post end opposite the cap end.
2. For each post, take a pair of split sleeves and place them on the lowest groove as shown. Be sure that the bead of the split sleeves fit securely into the groove of each post.
3. Stand one of the frames on its side. Insert a post from the underside of the frame. Repeat for the other three posts.
4. Use a rubber mallet and a towel to hit the corners of the frame down until the groove at the top of each sleeve is visible. Then, gently hit the side of each corner to ensure the sleeves are secure within the frame.



Assembly Instructions

5. Insert one of the slides into the assembled frame as shown so that the wires of the slide are interlocked with the frame wires. Push the frame down to securely lock in position. Repeat for the other slide.
Note: Gentle taps with the mallet can help secure each slide into the frame.
6. Place a pair of split sleeves on the top groove of each post. Be sure that the bead of the sleeves fit securely into the groove of the posts.
7. Place the second frame over the top of the assembled unit. Ensure the frame interlocks with the slides. Then, tap the frame down using the mallet until the groove in the sleeve is visible above the shelf collar.



Assembly Instructions

8. Insert the crutch tips into the top rod of the slides as shown.
9. Assembly complete.

