



MIXER

MODELS:

KSM8990CU1 (Contour Silver)


KSM8990ER1 (Empire Red)

KSM8990NP1 (Nickel Pearl)

KSM8990OB1 (Onyx Black)

KSM8990WH1 (White)


COLOR VARIATION PARTS



COLOR VARIATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing	4		Planetary	7		Base & Foot Assembly
	W10327951	Contour Silver		W11589994	Chrome		W10328017	Contour Silver
	9705300	Empire Red	5		Bowl Support and Pins		9705348	Empire Red
	9708749	Nickel Pearl		W10327966	Contour Silver		9708766	Nickel Pearl
	9705296	Onyx Black		9705360	Empire Red		9705344	Onyx Black
	9703311	White		9708760	Nickel Pearl		9703690	White
2		Trim Band		9705356	Onyx Black			
	W10540366	Dark Platinum		9703674	White			
3		Lower Gearcase	6		Column and Pins			
	W11630008	Contour Silver		W10328003	Contour Silver			
	W11589981	Empire Red		9705324	Empire Red			
	W11589984	Nickle Pearl		9708763	Nickel Pearl			
	W11589982	Oynx Black		9705320	Onyx Black			
	W11589983	White		9703673	White			


CASE, GEARING AND PLANETARY UNIT PARTS



CASE, GEARING AND PLANETARY UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing (Refer to Color Variation Parts Page)	7	W11518734	Assembly, Ring Gear and Plate	15		Planetary Assembly (Refer to Color Variation Parts Page)
2	W10394928	Cap, Attachment Hub, Hinged	8	3400617	Screw	16	W11533778	Pin, Groove
3		Trim Band (Refer to Color Variation Parts Page)	9	3400814	Screw	17	W11537260	Spring, Wave
4	W10351843	Screw	10	W10517938	Motor, 120 Volt Assembly	18	W11553110	Gear, Pinion
5	W10305968	Holder, Control	11	3400200	Screw	19	W10234531	Pin, Groove
6		Lower Gearcase (Refer to Color Variation Parts Page)	12	W10487697	Control Assembly, 120 Volt	20	8533910	Washer
			13	W10720795	Guard, Switch	21	W11531546	Shaft, Agitator
			14		Cord, Power	22	9703680	Clip, Retaining
				W11199160	Orange	23		Thumb Screw
							W10360791	Black

BASE AND PEDESTAL UNIT PARTS



BASE AND PEDESTAL UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	9708649	Foot	20	9703426	Cam, Adjusting
	W10581080	Use and Care Guide	10	9703307	Ring, Retaining	21	3400863	Screw
2	W10439369	Plug, Foot	11	W11376364	Rod, Bowl Lift	22	W11376371	Handle, Bowl Lift
3	W10508588	Bowl, 8 Quart	12	9237	Spring, Lift Rod	23	9706814	Screen, Vent
4	240185	Pin, Retaining Bowl	13	9703439	Washer	24	3400200	Screw
5	W10504114	Clip, Bowl Retainer	14	8533907	Nut			
6	3400018	Screw	15		Column and Pins (Refer to Color Variation Parts Page)			
7		Bowl Support and Pins (Refer to Color Variation Parts Page)	16	W10720793	Beater, Flat (Stainless)			
8		Base and Foot Assembly (Refer to Color Variation Parts Page)	17	W10720794	Hook, Dough (Stainless)			
			18	9706885	Arm, Bowl Lift			
			19	W10600940	Whip, Wire			