

# Use & Care Guide

## REVERSIBLE TABLE TOPS



LANCASTER™  
TABLE & SEATING



### ASSEMBLY/ARRIVAL

1. It is the responsibility of the recipient to inspect the shipment for damage prior to signing the bill of lading. Damages must be reported to your authorized retailer within 5 days of receipt.
2. Inspect table top for damage before use.
3. Please refer to any safety labels on packaging or resources that come with table top.
4. Always follow cleaning and maintenance instructions.
5. Please note, the tabletop is only reversible prior to the first assembly. As assembly requires drilling into the tabletop, reversing the tabletop after assembly will lead to unsealed holes in the table top surface that may allow water and debris in, leading to damage.



### STORAGE

1. After assembly, do not store upside down.



### ONGOING MAINTENANCE

1. It is recommended to use placemats and coasters to prevent scratches, scrapes, and warping.
2. Do not place hot items directly onto wooden tabletops. They may damage the finish. As this is the result of misuse, it may not be covered under warranty.



### CLEANING INSTRUCTIONS

1. Clean using a mild soap with warm water and a clean cloth. Recommended Cleaners: Noble AllSurf (999ALLSURF), Noble Strike (147STRIKEQT), Noble Reflect (147REFLECTQT).
2. Do not use abrasive cleaners or products.
3. Use a clean, dry cloth to dry and make sure material is fully dry before use to prevent warping or damage to the finish. As these are the result of misuse, they may not be covered under warranty.



### CAUTION

1. Always make sure table is stable and balanced.
2. Avoid scraping with sharp items/utensils.
3. Do not use if table top is broken or damaged.