

#257SRSS330


Rolling Step Stool

MAX LOAD: 330 lb.


ASSEMBLY TIPS

- Read instructions thoroughly before proceeding.
- Tighten all parts by hand. Do not use power tools.
- For your safety, please do not overload.


PARTS LIST



A Top Section



B Bottom Section




C Plastic Protector (x3)

STEP 1

Unwrap and remove any protective packing, including the plastic protectors outside the 3 legs.


Insert the pins of the 3 legs on the top section into the holes on the bottom section.



STEP 2

Press the top section down firmly until each leg is fixed tightly and safely with the bottom section.

NOTE: Return plastic protectors once installation is complete.



STEP 3

Installation is complete and the top and bottom sections are permanently connected. When stepped on, the casters will retract to provide a stable base. If needed, the step stool can be moved with a light nudge.

WARNING:

1. The step stool cannot be disassembled after assembly, otherwise the step stool will be damaged.
2. Do not use a hammer for assembly, as it will damage the step stool.
3. When stepping up or down, always use both steps.
4. Stand with both feet in the middle of the unit; never overstretch.
5. The step stool must be used on firm, level surfaces which are dry and grease-free.
6. Check at regular intervals that the casters work normally.
7. Do not use if the step stool is damaged.