








Parts List

A: Table top  1pc	B: Seats  6pcs C: Arms  3pcs	E: Full Base Supports  3pcs
--	--	--


Hardware	QTY
H1 : M8 x80mm 304 SS Countersunk Head Hex Screws 	24pcs
H2 : M8 x50mm 304 SS Hex Socket Cap Self Tapping Screws and Washers 	9pcs
H3: M8 x80mm 304 SS Hex Socket Cap Self Tapping Screws and Washers 	3pcs
H4: M8 x110mm 304 SS Hex Socket Screws and Nuts and Washers 	3pcs
H5 : M10 x80mm Concrete bolts and Washers 	3pcs

46" Recycled Plastic Hexagon Picnic Table

Step1

The three (3) base support legs and two(2) anchor blocks are rotated for shipping purposes. A single deck screw is pre-installed, rotate 90 degrees and align the pre-drilled holes. Secure the leg with screw. Repeat for all legs and anchor blocks.

H2 x3




Step2

Fasten the arms together with H2, two (2) per side.

C x3

H2 x6




Step3

Insert a base leg inside an arm with the pre-drilled hole in arm aligned on the base leg. Pre-install H4, not need tightened.

E x3

H4 x3



46" Recycled Plastic Hexagon Picnic Table


Step4

The seat flat edges aligned at the center point of the middle board of the arm.

① Attach seats to the Arms with H1 .

② Attach seats to the Anchor blocks of Base Supports with H1.



H1 x24 B x6



Step5

Attach the slots in the table top underside frame to the three (3) base legs, Ensure each base leg is fully engaged in the slot and the top is resting even and level.

A x1




46" Recycled Plastic Hexagon Picnic Table

Step6

- ① Attach the table top to the base legs with H3 (3)
- ② Fasten the arms and Base legs with H4 (3)

H3 x3



Step7

Secure the table to the floor with 3 screws.

H5 x3

