

SL1577 & CS1500 Recommended Cleaning Procedures

DO NOT use ice or cold water to cool unit down.
This causes the platens to warp.

TOOLS REQUIRED: 1. Proluxe Panini Scraper 2. Pad Holder 3. 3M Griddle Polishing Pad 4. Damp Washcloth



1. While grill is on press
"Clean" Button.



2. Wait for the unit to reach
clean temperature "275° F"
Display will flash until temp is
reached.



3. Use panini scraper to
remove debris from grooves.



4. Push debris to trough
located in the back right
corner.



5. Use only approved
aluminum griddle cleaners.



6. Apply a small amount of
cleaner onto the grill surface.



7. Scrub grill surface with
scrubber pad.



8. Scrub upper platen grill
surfaces.



9. Wipe down all grill surfaces
with a damp sanitized cloth.



10. Make sure to clean out
grease/crumb tray.