


# USAGE INSTRUCTIONS

Item #CSI-10




**CAUTION:** Use extreme care during insertion & removal of cartridge. Use extreme care when locking & unlocking the guard. Always cut away from your body and others.



Training video available on the Videos tab at [spellboundinc.com/cartridgeknife](http://spellboundinc.com/cartridgeknife)


2

## LOCKING & UNLOCKING GUARD



### TO LOCK

Using caution, grab sides of guard and gently pull on guard as show above.




### TO UNLOCK

Gently push guard against a flat surface.

1

## REMOVING & INSERTING CARTRIDGE



### TO REMOVE


Lock guard before removing (see step 2). Squeeze two release buttons and pull cartridge out of the handle.

### TO INSERT

Insert cartridge into handle until it clicks into place. Unlock guard before use (see step 2).

3

## TO USE



PRESS DOWN on cutting surface to expose blade and DRAG ALONG line of cut.  
**Make sure guard is in the unlocked position.**