



Naturale



INSTRUCTIONS FOR USE



IMPORTANT SAFETY INSTRUCTIONS – READ AND SAVE THESE INSTRUCTIONS

WARNING – when using electric appliances, basic precautions should always be followed, including the following:

- Read all the instructions before using the appliance.
- Keep out of the reach of children and pets.
- Only use adaptors and attachments recommended or sold by PestWest.
- Do not use outdoors.
- To disconnect this appliance, remove plug from outlet.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Unplug from outlet before servicing or cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. Please contact PestWest: 866.476.7378. We have no authorized service facilities.
- To reduce the risk of electrical shock, do not put the appliance in water or other liquid. Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Always unplug before replacing the lamp.
- Replace lamp with same type rated 18 Watts.
- The lamp is made of glass. Extra care should be given when replacing and ALWAYS use protective gloves to prevent injury should the glass break.
- See REPLACEMENT PARTS section.

CAUTION

- Do not install in wet or damp environments or... where dangerous concentrations of flammable gases or dusts are likely to occur.
- Unplug the system prior to any maintenance
- Ensure that operators have an adequate and secure working platform when working on the machines.
- Do not allow the glue board to become overfilled with dead insects. Change at regular intervals as required by the catch or at least every 8 weeks.

PRODUCT DESCRIPTION

This PestWest Naturale flying insect control system is made using the highest quality materials. The body work is made from Bamboo. The Naturale can be wall mounted or free standing on a table top or cabinet. The Naturale has a universal input range meaning it can operate from a wide range of supply voltages from 100-277V 50/60Hz, this allows the system to be used in many different countries (by simply changing the power cord to a type with a plug suited to the local outlet sockets)

UNPACKING YOUR SYSTEM

Each system is carefully inspected and packed before leaving our factory. Before discarding the outer carton, examine for obvious evidence of transport damage. Remove the system and pay particular attention to the removal of all packing materials including any transit packing. Including the release paper off the glue board.

MODE OF OPERATION

The PestWest Naturale fly trap operates on the principle that most flying insects are attracted to light, particularly to the ultraviolet (UV) end of the light spectrum. Since insects are still very active and will fly at night, traps should be left operating continuously, i.e.: 24 hours a day.

FINDING THE BEST PLACEMENT FOR YOUR SUNBURST

System efficacy can be affected by the intensity of other light sources (overhead lighting and daylight). Place or mount the system where competition from other light sources is minimal.

In food areas, place or mount close to, but not directly over, exposed food or preparation surfaces. Observe where flies tend to congregate and/or fly and then place or mount your system close to that area.

Place or mount the system(s) adjacent to fly ingress point(s), such as service and/or overhead doors and windows.

COVERAGE

Keep in mind that the brighter the surrounding indoor light and daylight, the greater the number of systems needed for optimum fly attraction.

INSTALLATION INSTRUCTIONS

The PestWest Sunburst has 2 keyhole slots on the rear panel for wall mounting. The Sunburst can be placed (free-standing) on a table or cabinet.

The system comes with a 6-foot power cord with IEC C14 connector at one end and a 3 pin grounded USA plug on the other end. The system will operate from a 100-277 volt 50/60Hz supply.

If the moulded-on plug is removed from the supplied cord, disposed of safely. Ensure that once installed, the power cord is adequately secured. Before installing any system, please remove all packaging.

Using the system as a template, mark off 2 drill holes onto the mounting surface. Using the screws and plastic plugs provided, hold the system in place at level. Note: If the wall is of drywall/sheet-rock, appropriate hardware must be used to ensure the system is secure.

Once installed, you will need to remove backing paper from the glue board to reveal the glued surface. Then slot the glue into the system.

USER-MAINTENANCE INSTRUCTIONS

DISCONNECT THE POWER BEFORE UNDERTAKING ANY SERVICING OR MAINTENANCE

To maintain the attractive appearance of the systems, it should be cleaned/wiped down as often as required. Use a cloth dampened with water and detergent or a proprietary cleaner. Do not use scouring pads or abrasives.

GLUE BOARD REPLACEMENT

Due to insect contamination the glue boards should be changed when full or at least every eight weeks. Always use PestWest glue boards to ensure peak efficacy. Remove the backing paper from the new board in a single swift motion; otherwise it will tend to remain firmly attached. Should this occur, re-apply the peeled back section and repeat.

Other brands of glue or glue boards may not have effective UV inhibitors that PestWest brand incorporates in this system, therefore, ONLY PestWest brand glue boards and components must be installed in the system. PestWest recommends an eight-week glue board replacement cycle. Your system may capture a wide range of insect pests. While the recommended eightweek board replacement cycle remains unaltered, the effective life of the glue for a wide range of insects is enhanced.

Simply remove the used glue board from the machine by pulling out of the front cover. Remove the release paper from the new glue board before putting it in the system. Insert the new glue board into the system by sliding it into the curved front so that the sticky surface is facing the lamp.

UV LAMP REPLACEMENT

Lamps are most attractive to the target flying insects when less than one year old. This is because the UV light emitted by the lamps at a wavelength of 350-375 nanometers diminishes with use. Light of this wavelength is invisible to the human eye. The blue/violet colored light, which we can see is not at all representative of the actual UV light emissions. Daily switching on and off of the lamps results in an even faster loss of the effective UV emission.

THEREFORE IT IS MOST EFFECTIVE TO LEAVE THE SYSTEMS SWITCHED ON CONTINUOUSLY AND TO CHANGE THE LAMPS AT LEAST ONCE PER YEAR (PREFERABLY AT THE ONSET OF INCREASED FLIGHT ACTIVITY AFTER THE WINTER).

Disconnect the power to the system before attempting to change the lamp. Wait for the lamp to cool before touching. The lamp has a push fit base, to remove the lamp, simply pull it upwards and it will unclip from the lamp holder. Installing the new lamp is a reversal of the above procedure.





REPLACEMENT PARTS

Lamp:
Standard: 130-000243
Shatter resistant: 130-000247 Qty: 1

Glue boards:
White: 135-000049
Black: 135-000074
Translucent (plastic): 135-000179



Lamp contains mercury (Hg), dispose or recycle in accordance with applicable laws. In US, consult www.lamprecycle.org or 1-800-922-6693 for measures to be taken in case of breakage; safe handling procedures; and recycling and disposal options. Outside of US, please contact your local authorities



Scan the QR code to register your 3-year warranty or visit;

<https://support.pestwest.com/pestwestwarranty/>



WARNING:
Cancer and/or Reproductive Harm
www.P65Warnings.ca.gov



Naturaale



California Residents Only
WARNING: Cancer and/or
Reproductive Harm
www.P65Warnings.ca.gov

PestWest Electronics Ltd operates a quality
management fly trap certified to ISO 9001

PestWest USA LLC
7135 16th Street E, Suite 124 Sarasota, FL 34243
Tel: 941.358.1983 | Fax: 941.358.1916 | Toll Free: 866.476.7378
Email: customerservice@pestwest.com

www.pestwest.com

Confidence in
Fly Control