



PROPER POUR™ SERIES

For an accurate pour every time

1. Before use: Soak in lukewarm, soapy water for 10 minutes. Rinse in cold water.
2. To install: Wet cork and push the pourer straight into the bottle.
To remove: Twist and pull straight up out of the bottle.
3. To pour: Hold the bottle at a 45° angle. If bottle is low, allow liquor to reach the neck of the bottle before tilting to a 45° angle. Bring spout of the lip to the glass and then raise the tail of the bottle.
4. To wash: Soak in lukewarm, soapy water. Rinse in cold water.
Wash weekly for spirits and daily for cordials or syrups.
5. If plastic cork fins flatten, run corks under hot water for 30 seconds and then run under cold water.
This will straighten fins.

**DO NOT RUN THROUGH DISHWASHER
OR WASH IN EXTREMELY HOT WATER**



Proper Pour



Proper Pour II



Proper Pour III

TABLECRAFT PRODUCTS CO.
801 Lakeside Drive
Gurnee, IL 60031-2489