

Gas **Wok Ranges**



351WOKR13L, 351WOKR13N, 351WOKR16L, 351WOKR16N





REVISED 07/2023



Contents

Safety Precautions	2
Gas Pressure	2
Whole Assembly Parts List	3
Whole Assembly Diagram	4

Safety Precautions

CAUTION:

• Failure to comply with the following operation instructions could lead to potential hazards and/or unsafe practice and could result in injury and damage to product and property.

NOTICE:

- Local codes regarding installation vary greatly from one area to another. The National Fire Protection Association, Inc., states in its NFPA96 latest edition that local codes are "Authority Having Jurisdiction" when it comes to requirement for installation of equipment. Therefore, installation should comply with all local codes.
- This product is intended for commercial use only. Not for residential use.

WARNING:

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other equipment.
- Improper installation, adjustment, alteration, service, or maintenance could lead to property damage, injury, or death. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing CPG equipment. This manual must be retained for future reference.
- A factory authorized agent must handle all maintenance and repair.

Gas Pressure

- The appliance and its individual shutoff valve (to be supplied by user) must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 PSI (3.45 kPa).
- The appliance must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1 / 2 PSI (3.45 kPa).



 Intertek
 Intertek

 5013731
 5013731

 Conforms to ANSI STD Z83.11-2016
 Conforms to CSA STD 1.8-2016



Whole Assembly Parts List

DIAGRAM #	ITEM NUMBER		DESCRIPTION	QTY	
	351WOKR13	351WOKR16		351WOKR13	351WOKR16
1	-	-	Elbow	1	1
2	-	-	Gas Pressure Test Nut	1	1
За	35121102C049	35121102C080	Lp Orifice	18	28
Зb	35121102C050	35121102C079	Ng Orifice	18	28
4	35121104C009	35121104C009	Duckbill Burner	18	28
5	-	-	Regulator	1	1
6	-	-	Leg Sleeve	4	4
7	351515001	351515001	Leg Assembly	4	4
8	351515002	351515002	Drip Pan	1	1
9	35120301C017	35120301C024	Burner	1	1
10	35121101C195	35121101C322	Pilot Tube	1	1
11	-	-	Intake Pipe	1	1
12	35120102C003	35120102C003	Pilot Valve	1	1
13	-	-	Burner Connecting Pipe	1	1
14	-	-	Steel Union	1	1
15	-	-	Elbow	1	1
16	351515009	351515009	Gas Valve With Handle	1	1



Whole Assembly Diagram

