

Cleaning & Maintenance

- 🍃 Keeping the dispenser as clean and properly maintained as possible will avoid repairs and extend the life of the dispenser.
- 🍃 All exterior surfaces should be wiped or dusted with a clean towel.
- 🍃 Occasionally wipe the bottom as dust can accumulate over time.
- 🍃 Keeping the dispenser as clean and properly maintained as possible will avoid repairs and extend the life of the dispenser.
- 🍃 Deep clean the inner components at least once a month to avoid contamination. Do not use a dishwasher to clean mechanism pieces.
- 🍃 Use mild soap or food-grade cleaning products to clean the dispenser, with a damp rag or good quality sponge.
- 🍃 Dry off with a clean towel, removing any excess water to avoid build-ups.
- 🍃 Avoid using strongly scented cleaning products. The chemicals could contaminate the dispenser and cutlery.
- 🍃 Moving the dispenser with cutlery installed is risky and should be avoided.
- 🍃 Do not tilt or lay down while loaded with utensils or while cleaning.
- 🍃 Do not pull the red side trigger if there is already cutlery in each tower as jamming might occur.
- 🍃 If any pieces of the dispenser do not work or are jammed, please watch the video below or call 707.241.9190 to get help with questions or repair.