

Step 1

Remove the core holder from the zcM0300 dispenser, load tape, and place the core holder back on the dispenser.



Step 2

Open the cover plate door on top of the zcM0300 and set the tapes leading edge on the rollers. Ensure that the leading edge of the tape is flat and close the cover plate door.



Step 3

Adjust the manual tape dispenser lever by setting the arm to the desired length. Loosen the knob on the lever and position the arm to obtain the proper length. Tighten the knob to set the dispensed length.



Step 4

Press down on the zcM0300 lever to dispense the tape at a consistent length. Pull the dispensed tape in an upward motion to cut the tape.



Questions? Call Us at +1 (972) 248-1999