

*Plates suitable for:  
Oven & Dishwasher*



# **DINNERWARE**

**ELEGANCE,  
SAHARA BLACK**

ELEGANCE, SAHARA BLACK



**ELE-24**  
Charger Plate  
11.875" | cp: 12



**ELE-1**  
Dinner Plate  
10.75" | cp: 24



**ELE-2**  
Luncheon Plate  
9.125" | cp: 24



**ELE-4**  
Salad/Dessert Plate  
8" | cp: 24



**ELE-5**  
Bread & Butter Plate  
7" | cp: 24



**ELE-3**  
Rim Soup  
9", 8oz. | cp: 24



**ELE-9**  
Can Cup/Saucer  
8 oz | cp: 24



**SAH-3BK**  
Rim Soup  
9", 8 oz | cp: 24



**SAH-9BK**  
Can Cup/Saucer  
8 oz | cp: 24



**SAH-16BK**  
Creamer  
8 oz | cp: 6



**SAH-24BK**  
Charger Plate  
11.875" | cp: 12



**SAH-1BK**  
Dinner Plate  
10.75" | cp: 24



**SAH-2BK**  
Luncheon Plate  
9.125" | cp: 24



**SAH-4BK**  
Salad/Dessert Plate  
8" | cp: 24



**SAH-5BK**  
Bread & Butter Plate  
7" | cp: 24

