Griddle Kleen Chrome

NOBLE CHEMICAL INC.

Loosens And Lifts Baked-on Food & Grease From Griddle Surfaces Heat Activated

Distributed by: Noble Chemical, Inc. 2205 Old Philadelphia Pike Lancaster, PA 17602 1-888-256-6400



GENERAL DESCRIPTION

GRIDDLE KLEEN CHROME is a heat activated, glycerin-based grill cleaner for use in commercial and institutional kitchens. This fast acting formula easily loosens and lifts cooked on grease and soil eliminating the need for scrubbing, scraping, and scouring. GRIDDLE KLEEN CHROME is also nonflammable, non-toxic, and safe for use on hot surfaces, so there is no need to shut down the grill prior to use.

DIRECTIONS

Evenly pour a thin layer of GRIDDLE KLEEN CHROME over hot griddle surface (300° - 350°F). Immediately spread the liquid with a compatible high heat sponge over the entire cooking area and gently scrub heavily soiled spots as needed. Allow a thin layer of GRIDDLE KLEEN CHROME to remain in contact with the warm grill surface for a few minutes. Then, wipe or squeegee into grease trap. Turn off griddle. Rinse surface and wipe clean with a thick damp cloth. Apply a thin coating of liquid shortening to prevent surface from rusting.

PROPERTIES:

Chemical CompositionViscosity modifiers,
alkaline builders, organic stable surfactants, rinsing agents,
water conditions, soil suspending agents.
Appearance Clear, orange liquid
pH, 1% Solution10.4
Specific Gravity1.235
BiodegradableYes
CausticNo
Metal Safety Safe on iron,
steel, stainless steel, nickel, procelain, and glass. May be used on
enamel and paint, Safe on soft metals, too.

ALWAYS USE GLOVES WHEN CLEANING OR RINSING HANDLING PRECAUTIONS: CAUTION - FIRST AID

EYES:

Flush with water for at least 15 minutes. If irritation persists, obtain medical attention.

SKIN:

Wash with plenty of water for 15 minutes. If irritation occurs and persists, obtain medical attention.

INHALATION:

Remove from exposure. If discomfort occurs and persists, obtain medical attention.

INGESTION:

Drink water to dilute. Obtain medical advice by phone.

DECONTAMINATION PROCEDURE:

Wash with soap and water.

KEEP OUT OF REACH OF CHILDREN

PACKAGING:

4 x 32 oz. (1 Quart) bottles / case

Seller makes no warranty, expressed or implied, concerning the use of this product other than indicated on the label. Buyer assumes all risk of use and/or handling of this material when such use and/or handling is contrary to label instructions.