

Handle for tray

Article number: DV0344

For use with Merrychef eikon® model(s): □ e2 ☑ e2s □ e3 ☑ e4 ☑ e4s □ e5

Key benefits:

• Griddle carrier handle for use with PSA1108 and PSB3117



Specifications:

• Dimensions: 25 mm x 250 mm x 76 mm (1" x 9.8" x 3")

Recommended application:

To be used for taking the griddle plate or the grooved cook plate in and out of the high speed oven

Cleaning:

Wipe clean with a soft cloth or sponge in warm soapy water. To avoid damage always follow the recommended cleaning procedure. Do not use hard abrasives or wire wools on accessories.

