

PM 168 TWIN - CODE 180

PM 120 TWIN - CODE 170

PM 96 TWIN - CODE 160

- HOLDING CAPACITY: PM 168 168 plates
PM 120 120 plates
PM 96 96 plates
- TOTAL HEIGHT: PM 168 186 cm
PM 120 158 cm
PM 96 138 cm
- LENGTH OF UNDERCARRIAGE: PM 168, PM 120, PM 96 120 cm
- WIDTH OF UNDERCARRIAGE: PM 168, PM 120, PM 96 60 cm
- NET WEIGHT: PM 168 31,6 kg
PM 120 25,7 kg
PM 96 23,6 kg
- GROSS WEIGHT: PM 168 34 kg
PM 120 28 kg
PM 96 26 kg
- BOX UNDERCARRIAGE: PM 168, PM 120, PM 96 60 X 121 X 19 cm
- 2 X BOX COLUMN: PM 168 19 X 19 X 175 cm
PM 120 19 X 19 X 147 cm
PM 96 19 X 19 X 127 cm

1 KG= 2.2 LBS
1 Inch=2.54 cm

The PM TWIN models are new in the PLATE MATE range.

You will find that these models are available in three versions, the PM 168 Twin for 168 plates, the PM 120 Twin for 120 plates and the PM 96 Twin for 96 plates. The PM 168 Twin is the largest PLATE MATE in the range. The columns can turn independently of each other in the frame full of plates with a diameter of up to 33 cm. Corrosion resistant materials are used in the construction, for example, the frames are made from stainless steel and the columns from aluminum and plastics. Cleaning can be done easily with a high-pressure cleaner or with a brush and a cleaning agent. To protect pre-prepared dishes or deep away odors, a protective covering is available for every PM Twin model.

Plate Mate:
The biggest space save.
www.plate-mate.com



PM 168 TWIN - CODE 180

PM 120 TWIN - CODE 170


PM 96 TWIN - CODE 160

ASSEMBLY

When mounting the PLATE MATE, proceed as follows:

1. Take the cart, the swivel wheels and the bridge posts + coupling unit out of the box.
2. Check if the swivel wheels have been mounted; if not, mount them using the nuts M10.
3. Place the cart with the swivel wheels on the floor.
4. Take the PLATE MATE columns and the two stainless steel runners out of the box.
5. Mount the two stainless steel runners into the tubes on the cart and mount the screws 3, 5 X 19 mm.
6. Put the two plastic slip-on caps over the tubes and over the screws.
7. Mount the coupling unit between the bridge posts by sliding them into the tube and tapping them in with a rubber hammer.
8. Mount the columns into the cart.
9. Put the columns into the foot on the cart and mount the bridge (bridge posts + coupling unit) on the cart with columns. The centering-pins fits through the bridge exactly in the column heads. Now your PLATE MATE is ready.

Maintenance: Cleaning can be done with a high-pressure cleaner or with a brush and a cleaning agent. To protect pre-prepared dishes or keep away odors, a protective covering is available for every PM Twin model.



PARTS LIST PM 168/120/96 TWIN Code 180/170/160



Part Name	Part No.	Quantity
Aluminum main column	varied	2
Adjusting screw - M6 X 60	01	8
Plastic hood	02	2
Hoisting block	03	8
Extension piece	04	8
Bracket set	05	varied
Black stay cap	06	varied
Red shuttle	07	varied
Corner bracket Right	08	varied
Corner bracket Left	08A	varied
Plastic foot - hole 10 mm	09	2
Plastic end parts in column	11	8
Column connecting screw -M10 X 40	TW1	2
Nut self locking -M10	TW2	2
Washer - 30 X 10 mm	TW3	2
Stainless tube bridge posts	TW4	1
Centering pin 10 X 70 mm	TW5	2
Plastic corner connection pieces	TW6	2
Stainless steel longitudinal runners	TW7	2
Screws - 3, 5 X 19 mm	TW8	2
Plastic Slip-on caps	TW9	2
Stainless base - 1200 X 600 mm	TW10	1
Swivelling wheel (with brake) - 125 mm	TW11	2
Swivelling wheel - 125 mm	TW12	2