



- Antimicrobial & adjustable head:
Pivots in 8 different angles
- Adjustable stainless steel pan clip
- Data-hold mode
- Auto-off after 15 minutes



DIGITAL CANDY THERMOMETER

#9149DIGCTAF

TEMPERATURE RANGE	-58-572°F, -50-300°C
ACCURACY	+/- 2°F, +/- 1°C
DISPLAY TYPE	LCD
DISPLAY SIZE	1.875" W x 0.8125" H
HOUSING MATERIAL	ABS Plastic
STEM MATERIAL	Stainless Steel
STEM LENGTH	8¾"



08/2021



BATTERY

(1) LR44 battery included. Use a coin to open and seal the case for battery replacement.

INSTRUCTIONS

- 1) Press the **ON/OFF** button to turn on.
- 2) Select temperature mode by pressing the °C/°F button on the back of the thermometer.
- 3) Insert the probe into both holes of the clip.
- 4) Attach clip to the side of a pot or pan to record candy or fry oil temperature.
- 5) Press the **ON/OFF** button to turn off (*the thermometer will automatically turn off after 15 minutes of inactivity*).

DATA-HOLD MODE

While the probe is in the pot or pan, press the **HOLD** button to hold the current temperature reading. **HOLD** will display to the right of the temperature. Press the **HOLD** button again to exit the hold mode.

NOTE

Probe should not come into contact with pot or pan. This will provide inaccurate temperature readings.

WARNING

Hand wash only. Not for oven use.

1 YEAR WARRANTY

AvaTemp warrants its products to be free from defects in material and workmanship for a period of 1 year, unless otherwise stated. This is the sole and exclusive warranty made by AvaTemp covering your AvaTemp brand product. A claim under this warranty must be made within **1 year** from the **date of purchase** of the product. Only the product's original purchaser may make a claim under this warranty. AvaTemp reserves the right to approve or deny the repair or replacement of any part or repair request. The warranty is not transferable.