

BACKYARD PRO

Backyard Pro Knob for Outdoor Burners

#554PSQ2150KB



Technical Data


Type	Knobs
------	-------

Features

- Direct replacement for the original part
- Fits outdoor burners

Notes & Details

Replace a broken or missing part on your outdoor cooking unit with this Backyard Pro knob for outdoor burners. This knob is a direct replacement for the one that came with your unit so that you can quickly make repairs and get your outdoor cooking equipment back up and running.

 **WARNING:** This product can expose you to chemicals including lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.p65warnings.ca.gov.