



Backyard Pro Courtyard Series 10' x 10' Blue Straight Leg Steel Instant Canopy

#554BP10X10B



Technical Data

Length	10 Feet
Width	10 Feet
Maximum Side Height	79 Inches
Canopy Size	10' x 10'
Color	Blue
Features	UV Resistant
Frame Material	Steel
Shape	Square
Style	Straight Leg
Type	Canopies

Features

- Provides up to 100 sq. ft. of shelter for patrons, employees, and equipment
- Rising truss ceiling system offers additional headroom
- Easy-to-use canopy sets up quickly to save time and labor during event preparation; stakes and ropes not included
- Top is waterproof, flame-retardant, and filters out harmful UV rays
- Steel frame features a powder-coated finish

Notes & Details

This Backyard Pro 10' x 10' blue straight leg steel instant canopy offers commercial grade durability with recreational grade portability and affordability, making it easy to work your next event in style and comfort! This canopy provides an easy way to draw attention at trade shows or provide shade and shelter during outdoor events. Its powder-coated steel frame and eye-catching blue canopy top combine to ensure optimum visibility, near or far.

This Backyard Pro canopy features a rising truss ceiling system that combines the benefits of the full truss system's strength with reinforced truss bars, offering additional headroom similar to a cathedral-style frame. The steel frame is durable and built to withstand heavy use. It's perfect for outdoor events, providing up to 100 sq. ft. of shade beneath the 10' x 10' canopy. Plus, the 4-legged design ensures stability and safety for staff and guests alike.

This canopy is waterproof, providing shelter for your guests, equipment, and employees and the top fits snugly over the frame for a seamless look and easy setup. This canopy is so simple to set up, it only takes a few minutes with the work of two employees to complete saving time and labor during event preparation! Set the frame on its feet. Begin pulling the legs out while still keeping the top of the frame at an easily reachable level. Once the frame is partly expanded, add the cover on top with each corner fitting over a leg. Continue to pull the legs in opposite directions until they're out as far as they will go and lock into place. Finally, raise the height of each leg by lifting the upper portion, stopping when each leg locks into place. Tear down is just as easy. Remove the top, adjust the legs back to their lowest height, disengage each corner's locking button, and gently push together until the frame is once again folded fully. A roller bag is included to ensure that you have an easy way to store and transport the canopy frame.

 **WARNING:** This product can expose you to chemicals including lead, which are known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, go to www.p65warnings.ca.gov.