



# options



### flat coupe plate

- 711215 5.9" ④♥
- 711217 6.7" ④♥
- 711220 7.9" ④♥
- 711223 9.1" ④♥
- 711226 10.3" ④♥
- 711228 11.1" ④♥
- 711230 11.8" ④♥
- 711232 12.5" ④♥



### flat square coupe plate

- 711915 5.3" x 5.3" ④♥
- 711920 7.6" x 7.6" ④♥
- 711927 9.7" x 9.7" ④♥
- 711932 11.3" x 11.3" ④♥



### flat triangular coupe plate

- 711511 4.1" x 4.1" ④♥
- 711520 7.5" x 7.5" ④♥
- 711525 9.6" x 9.6" ④♥
- 711532 11.0" x 11.0" ④♥



### exquisite deep plate with wide rim

- 070724 9.5" 11.8 oz ④♥
- 070728 11.2" 16.9 oz ④♥



### half-deep coupe plate

- 711424 9.4" 22.0oz ④♥
- 711428 11.1" 29.4oz ④♥
- 711431 12.1" 40.6oz ④♥



### deep coupe plate

- 711318 7.1" 17.6oz ④♥
- 711324 9.4" 33.8oz ④♥
- 711330 11.9" 57.5oz ④♥



### square coupe pasta bowl

- 711830 10.6" x 10.6" 35.8oz ♥④



### triangular coupe pasta bowl

- 711630 10.4" x 10.4" 38.2oz ④♥



### flat rectangular coupe platter

- 712314 5.5" x 3.7" ④♥
- 712328 10.9" x 7.2" ④♥
- 712332 12.6" x 9.1" ④♥
- 712336 14.2" x 9.1" ④♥



### flat rectangular coupe platter

- 712341 16.3" x 8.3" ④♥



### bloom bowl

- 076209 5.1" x 3.7" 1.7oz ④♥
- 076214 7.5" x 5.5" 6.1oz ④♥
- 076218 10" x 7.3" 10.1oz ④♥



### bowl

- 713014 5.6" 10.8oz ④♥
- 713016 6.5" 17.2oz ④♥



### bowl

- 716526 4.1" 9.1oz ④♥
- use with saucer 716918, 717188



### cream soup cup

- 712726 4.1" 8.8oz ④♥
- use saucer 716918, 717118



### stackable cream soup cup

- 712826 3.9" 9.1oz ④♥
- use saucer 716915



### demitasse cup

- 715159 2.4" 3.0oz ④♥
- use with saucer 716909, 717009



### cup

- 715168 3.0" 6.1oz ④♥
- use with saucer 716918, 717188
- 715172 3.0" 7.4 oz ④♥
- use with saucer 716918, 717188



### cup

- 715176 4.1" 8.8oz ④♥
- use saucer 716918, 717118
- 715190 4.7" 14.9oz ④♥
- use saucer 716940, 706885



### cup

- 715626 3.0" 8.8oz ④♥
- use saucer 716918, 717118
- 715628 3.0" 9.5oz ④♥
- use saucer 716918, 717118



### teacup without handle

- 715315 3.4" 5.1oz ④♥
- use saucer 716918



### tea cup

- 725172 4.1" 7.4oz ④♥
- use saucer 716918



### stackable mug

- 715317 2.8" 6.4oz ④♥
- use saucer 716915, formerly 195317



demitasse saucer  
716909 4.7" ② ♻️ ♡



triangular demitasse saucer  
717009 4.1" x 4.1" ② ♻️



saucer  
716918 5.9" ② ♻️ ♡  
716940 7.5" ②



saucer square  
717118 5.4" x 5.4" ② ♻️ ♡



saucer  
716915 5.8" ② ♻️ ♡  
formerly 196915



creamier without handle  
714605 2.2" 1.7oz ② ♡



creamier with handle  
714715 3.8" 5.1oz ② ♡



complete coffee pot  
714130 5.0" 10.1oz ②  
coffee pot bottom  
714131 5.0" 10.1oz ②  
coffee pot cover  
714132 1.7" ②



complete teapot  
714335 6.0" 11.8oz ② ♡  
teapot bottom  
714336 6.0" 11.8oz  
teapot cover  
714337 2.2" ②



oval sauce boat  
713810 4.3" x 2.4" 2.7oz ② ♡  
713364 5.6" x 3.3" 9.1oz ② ♡



egg cup  
714001 2.0" ②  
use with saucers 716909, 717009, 097010



salt shaker  
714010 1.9" ② ♡



pepper shaker  
714020 1.9" ② ♡



flower vase  
718100 2.7" ②



candleholder  
717700 2.7" ②



porcelain spoon  
717900 5.1" x 1.8" ②



chopstick rest  
717901 2.6" x 0.8" ②



complete round etagère  
717301 10.3" ②  
coupe plate etagère  
717203 8.0" ②  
717202 10.3" ②  
metal stand for etagère  
697802 ②



complete square etagère  
717302 10.8" ②  
square plate etagère  
717206 7.6" x 7.6" ②  
717205 9.7" x 9.7" ②  
metal stand for etagère  
697802 ②



varied shapes can be mixed to create countless arrangements