

DIGITAL CANDY THERMOMETER

With seven preprogrammed candy stages and one all-purpose temperature setting, CDN's Digital Candy Thermometer provides easy control over candy and other high temperatures. The thermometer features dual progress display, and sounds alert warnings before, during, and at key temperatures in the candy range.



SPECIFICATIONS

Measurement Range:	14 to 450°F/-10 to 232°C
Display Size:	0.875 W x 0.875 H (in)/ 2.2 W x 2.2 H (cm)
Power:	2 LR44 batteries included
Weight:	2.6 oz/56.7 g
UPC:	0 18436 00506 3
Other:	<ul style="list-style-type: none"> • 8.5"/21.6 cm stem • Shatterproof • ABS plastic case • Adjustable stainless steel clip • Temperature guide on sheath • Pocket clip

AVAILABLE

Now shipping



FEATURES

- Seven preprogrammed candy stages and one all-purpose temperature setting
- Dual progress display shows 2 temperatures — the set temperature and the current temperature.
- Thermometer sounds alert warnings 3°F before the low temperature, during the range, and at the high end of the range. During the two deep fry settings, the alert only sounds at the set temperature.
- Adjustable stainless steel clip to attach thermometer to pan
- Heat shield for high temperature use
- Protective sheath with temperature guide
- Auto shut-off after 1 hour

