



Flat plate with rim
Assiette plate à aile
Teller flach mit Rand
Plato llano con ala
Piatto piano con falda

28 cm / 11"

■ FRNOFP28GR
■ FRNOFP28RD
■ FRNOFP28OR



24 cm / 9.45"

■ FRNOFP24GR
■ FRNOFP24RD
■ FRNOFP24OR

6



Deep plate
Assiette creuse
Teller tief
Plato hondo
Piatto fondo

27 cm - 4 cm - 140 cl
10.65" - 1.55" - 47.35 oz

■ FRNODP27GR
■ FRNODP27RD
■ FRNODP27OR



23 cm - 4 cm - 95 cl
9.05" - 1.55" - 32.10 oz

■ FRNODP23GR
■ FRNODP23RD
■ FRNODP23OR



20 cm - 4 cm - 68 cl
7.85" - 1.55" - 23 oz

■ FRNODP20GR
■ FRNODP20RD
■ FRNODP20OR



6



Rimless flat plate / lid for deep plate
Assiette plate sans aile / couvercle pour assiette creuse
Teller flach ohne Rand / Deckel für Teller tief
Plato llano sin ala / tapa para plato hondo
Piatto piano senza falda / Coperchio per Piatto fondo

27 cm / 10.65"

■ FRNOLD27GR > FRNODP27GR
■ FRNOLD27RD > FRNODP27RD
■ FRNOLD27OR > FRNODP27OR

23 cm / 9.05"

■ FRNOLD23GR > FRNODP23GR
■ FRNOLD23RD > FRNODP23RD
■ FRNOLD23OR > FRNODP23OR

6



Bowl
Bol
Schale
Bol
Coppetta

16 cm - 7 cm - 100 cl
6.30" - 2.75" - 33.80 oz

■ FRNOBW16GR
■ FRNOBW16RD
■ FRNOBW16OR

6



14 cm - 6 cm - 68 cl
5.50" - 2.35" - 23 oz

■ FRNOBW14GR
■ FRNOBW14RD
■ FRNOBW14OR



20 cm / 7.85"

■ FRNOLD20GR > FRNODP20GR
■ FRNOLD20RD > FRNODP20RD
■ FRNOLD20OR > FRNODP20RD

12



12 cm - 5 cm - 48 cl
4.70" - 1.95" - 16.25 oz

■ FRNOBW12GR
■ FRNOBW12RD
■ FRNOBW12OR

12

■ Green
■ Red
■ Orange