

Back Guard Rail

For use with choral risers



Model #	Description
GRR24S	Back Guard Rails for 3 Level Straight Standing Choral Risers
GRR32S	Back Guard Rails for 4 Level Straight Standing Choral Risers
GRR24T	Back Guard Rails for 3 Level Tapered Standing Choral Risers
GRR32T	Back Guard Rails for 4 Level Tapered Standing Choral Risers
GRTPR3	Back Guard Rails for 3 Level TransPort Riser
GRTPR4	Back Guard Rails for 4 Level TransPort Riser

Side Guard Rail

For use with standing risers in 3 heights



Model #	Description
SGRTP3	Side Guard Rails for 3 Level TrasPort Riser
SGRTP4	Side Guard Rails for 4 Level TrasPort Riser
SGR2L	Side Guard Rails for 2 Level Standing Choral Risers
SGR3L	Side Guard Rails for 3 Level Standing Choral Risers
SGR4L	Side Guard Rails for 4 Level Standing Choral Risers

Chair Guard



Model #	Description
CG28	Chair Guard for SP368 Stage Pie
CG32	Chair Guard for Sides of 3'x8' Stages
CG37	Chair Guard for SP488 Stage Pie
CG44	Chair Guard for Sides of 4'x8' Stages
CG54	Chair Guard for SP3616 & SP4824 Stage Pie (2 EA. Needed for SP4824)
CG72	Chair Guard for SP4816 Stage Pie
CG81	Chair Guard for SP3624 Stage Pie
CG96	Chair Guard for Back of Stages (3'x8' & 4'x8')

Dolly

For use with stages & seated risers (Minimum 36" wifths)



Model #	Description
SDL	Stage Dolly for Use with 36" or 48" W Stages



Steps

For stages in 3 heights



Model #	Description
STP16	Steps for 16"H Stages
STP24	Steps for 24"H Stages
STP32	Steps for 32"H Stages

Stage Guard Rail


For use with stages



Model #	Description
GRS30	30"W Guard Rail for Stages
GRS36	36"W Guard Rail for Stages
GRS48	48"W Guard Rail for Stages

Skirting Options

Model Number Configuration



Type




Box pleat skirting (SB)



Shirred pleat skirting (SS)

Color



Length



Height



See our Full Stage & Risers Overview Guide!

[Click Here!](#)

