



NICKEL SAFE

ARCTIC

ICE MACHINE CLEANER CONCENTRATE

ARCTIC Ice Machine Cleaner is specifically designed for removal of mineral build-ups which can lead to bacterial contamination in ice machine equipment, protecting the nickel plated evaporator in ice machines.



Distributed by Noble Chemical, Inc.
2205 Old Philadelphia Pike, Lancaster, PA 17602

For customer service or for more ingredient information visit:
www.NobleChemical.com or call: 1-888-256-6400

Solely for Industrial Use
NET WT. 1 GALLON

DANGER

HAZARD STATEMENTS

Causes severe skin burns and eye damage



PRECAUTIONARY STATEMENTS

Prevention: Do not breathe dust/fume/gas/mist/vapors/spray.

Wash face, hands, and any exposed skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection.

General Advice: Immediately call a POISON CONTROL CENTER or doctor/physician. **Eyes:** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do so. Continue rinsing. Immediately call a POISON CONTROL CENTER or doctor/physician. **Skin:** IF ON SKIN (or hair): Take off all contaminated clothing immediately. Rinse skin with water/shower. Wash contaminated clothing before reuse. **Inhalation:** IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. **Ingestion:** IF SWALLOWED: Rinse mouth. DO NOT induce vomiting. Immediately drink large quantities of raw egg, milk, or milk of magnesia, then drink large quantities of water. Follow with vegetable, olive, or mineral oil. **Fire:** None.

Spills and Leaks: None. **Storage:** Store locked up. **Disposal:** Dispose of contents/container to an approved waste disposal plant.

HMIS Hazardous Materials I.D. System
Health 2 | Flammability 0 | Reactivity 0

DIRECTIONS

To clean ice machine: add 2 oz. of Noble Chemical ARCTIC Ice Machine Cleaner per 1 gallon of water and let circulate for 10 minutes. Brush on all surfaces as needed. Fill reservoir and rinse all surfaces with fresh water. Allow fresh water to circulate for 2 minutes to flush. To sanitize ice machine, use Noble Chemical QuikSan Ice Machine Sanitizer as directed.

INGREDIENTS:

PHOSPHORIC ACID (CAS# 7664-38-2), WATER (CAS# 7732-18-5), MODIFIED ALKYL ARYL POLYETHER (CAS# 60864-33-7), COLORANT



999ARCTIC1G

