



BIOHAZARD

SPILL MOP



SAFELY REMOVE

BIOHAZARD SPILLS

REDUCE CROSS CONTAMINATION

Biohazard spills can be especially difficult to remove, causing sanitation and safety concerns for patients and staff. Using a traditional mop and bucket can increase the chance of contact with biohazard materials. The new Rubbermaid Commercial Products' Biohazard Spill Mop safely and quickly removes spills and helps to prevent cross contamination.



A person wearing blue scrubs and blue gloves is using a yellow mop to clean a spill on a wood-grain floor. The mop has a white pad that is absorbing the liquid. The background shows a clinical setting with a green floor and medical equipment.

BETTER HEALTH &

SAFETY COMPLIANCE

Biohazard Spill Mop Pad material is designed to absorb bodily fluid and blood and turn it into a gel to prevent dripping and help make biohazard spill cleanup safe. The mop easily attaches to the mop head and includes an integrated release lever to dispose of the soiled mop, minimizing contact with hazardous materials.



HIGHLY ABSORBENT

Absorbs up to 13 ounces (0.4L) NaCl 0.9% or 32 ounces (0.94L) of water, leaving the floor drier.



NO DRIPS OR LEAKS

Absorbed liquid is locked inside to prevent drips or leaks.



DISPOSABLE

Quick and convenient. A clean mop every time helps prevent cross-contamination.



SAFE DISPOSAL

Integrated release lever helps avoid contact with soiled mop during disposal.

STORE WHERE SPILLS HAPPEN

Biohazard spills can happen anywhere, including patient rooms and other places where space and storage is limited. The Biohazard Spill Mop Pads come in a compact dispensing carton and the handle is collapsible to fit in drawers or under desks. A mountable storage unit can be placed in high traffic areas.

COMPACT DESIGN

Mop pads and telescoping handle fit in tight spaces.



CONVENIENT STORAGE

Storage unit mounts to wall to keep mop pads and handle close at hand.





Rubbermaid
Commercial Products

USAGE INSTRUCTIONS

1. ATTACH MOP HEAD TO HANDLE.
2. SPRAY CLEANER ONTO SPILL.
3. STEP IN CENTER OF SPILL.
4. PULL MOP HEAD TOWARD YOU.
5. REMOVE MOP HEAD FROM SPILL.
6. DISPOSE OF MOP HEAD.

REFILL SKU#
R-10101 (Replacement Mop Pads)

SPILL MOP STORAGE CABINET
R-10100 (Spill Mop Cabinet)

SPILL MOP PADS
R-10101 (Replacement Mop Pads)

BIOHAZARD SPILL MOP PADS
R-10101 (Replacement Mop Pads)

SPILL MOP HANDLE
R-10100 (Spill Mop Cabinet)

© 2018 Rubbermaid Commercial Products, Inc. All rights reserved.





ITEM #	DESCRIPTION	COLOR	COLLAPSED LENGTH	EXTENDED LENGTH	WIDTH	HEIGHT	DEPTH
▶ PRODUCT LINE							
2017059	SPILL MOP PADS 10 CT	GRAY	N/A	N/A	7.3"	10"	3.34"
2017060	BIOHAZARD SPILL MOP PADS 10 CT	YELLOW	N/A	N/A	7.3"	10"	3.34"
2017161	SPILL MOP HANDLE	YELLOW	22.18"	47.54"	3.99"	N/A	N/A
2017162	SPILL MOP STORAGE CABINET	GRAY	N/A	N/A	13.27"	24.6"	4"
2031093	SPILL MOP KIT*	GRAY	N/A	N/A	13.27"	24.6"	4"
2031094	BIOHAZARD SPILL MOP KIT**	GRAY	N/A	N/A	13.27"	24.6"	4"

*Spill Mop Kit includes: 1 Spill Mop Pads 10 ct, 1 Spill Mop Handle, and 1 Spill Mop Storage Cabinet

**Biohazard Spill Mop Kit includes: 1 Biohazard Spill Mop Pads 10 ct, 1 Spill Mop Handle, and 1 Spill Mop Storage Cabinet

*Image shown contains items 2031094 and 2017060



RCP-J1177 | 174470
 ©2017 Rubbermaid Commercial Products LLC
 8900 Northpointe Executive Drive, Huntersville, NC 28078

To see our complete range of cleaning solutions visit our online catalog at RubbermaidCommercial.com