

MAINTENANCE GUIDE

GENIEGRIPS® STIK-IT PADS

STEP 1:

Raise Tynes to Waist

SAFELY raise forktynes to waist height.



STEP 2:

Clean Surface

Using warm soapy solution, remove any grease, oil, paint, ice, grit, etc...



STEP 3:

Dry Surface

Using dry cloth remove any moisture or residue



Check for Wear & Tear

However, if your GenieGrips® Stik-It Pads have excessive tearing and damage to the rubber as in the images below, replace with a new Pad or please contact your GenieGrips representative to order replacement units.



Removal of Pads

Once the Pads have started to come away from the tyne, it is time to replace the Pad.

Peel the Pad from the tyne and go to Step 1 of How To Fit GenieGrips® Stik-it Pads

