

Soap dispenser / sterilizer bracket installation

Installation procedure (refer to the illustration below):

- 1• Turn extension rod into base plate;
- 2• Fix mounting plate of soap dispenser or sterilizer on back
 - plate with accompanying screws and nuts;
- 3• Hang back plate on extension rod and tighten with plastic nut;
- 4• Fix back plate on extension rod with fixing screws and pipe clamp;
- 5• Put drip pan on back plate , installation finished.

Name of parts:

Name	Number
Base plate	1
Extension rod	1
Plastic nut	1
Back plate	1
Fixing clamp	1
Fixing screw	1
Drip plate	1
Hexagon wrench	1
Screws M4x10	3
Nuts M4	3
Sticker	1

Notes: height of bracket is adjustable, when adjusting please loosen the telescopic handle first.

