

Model 9150

Probe Wipes

1. Tear two (2) packet corners along dotted lines
2. Place probe through tears in packet
3. Fold packet around probe
4. Pull probe back and forth through packet, applying slight pressure on the packet until probe is wiped clean
5. Remove probe from packet and allow to dry
6. Throw used packet away

9150 La tintera Enjuga

1. Rompa dos (2) rincones de paquete por líneas de puntos
2. Coloque la tintera por lágrimas en el paquete
3. Doble paquete alrededor de la tintera
4. Tire la tintera de aquí para allá por paquete, aplicando la presión leve en el paquete hasta que la tintera sea enjugada limpio
5. Quite la tintera del paquete y permita secar
6. El tiro utilizó paquete lejos.

9150 La sonde Essuye

1. Déchirer deux (2) les coins de paquet le long des lignes marquées avec des points
2. Placer la sonde par les déchirures dans le paquet
3. Plier le paquet autour de la sonde
4. Tirer la sonde de long en large par le paquet, appliquant de la pression insignifiante sur le paquet jusqu'à ce que la sonde est essuyée propre
5. Enlever la sonde du paquet et permettre de sécher
6. Le lancement a utilisé le paquet loin