

PART # 92642531
ECO # 153453



HYDRION[®] QT- 44 QUATERNARY TEST PAPER

Calibrated specifically for SSDC Supersan Sanitizer, QT-44 can also be used for SSDC Sani-quad

- Each kit consists of a 15 ft. roll of premium test paper in a handy dispenser, plus a matching color chart
- Approximately 100 tests per kit

Item	Quat Type	Range	Color Match Points
QT-44	4-Chain	0 – 400	0-150-200-300-400

Directions for use:

- Dip a strip of paper into the solution to be tested.
- Hold in still solution for 10-seconds; do not agitate.
- Remove and immediately compare to color chart.
- The sanitizer concentration will be associated with the closest matching color.

For accurate results, solution tested should be at room temperature (between 65°F - 75°F) and a pH of 7.5 or lower. Deviation from these instructions may result in erroneous readings.

Storage

QT-44 should be stored at room temperature and protected from extreme humidity, moisture and acid or alkali fumes. The shelf life is two years under the above-listed conditions.