



Hot Dog Roller Grills

 ϵ

Models: RG1824

9/2014


Please read and keep these instructions. Indoor use only.



Product Features

- 1. Avantco Equipment's hot dog roller grills feature a convenient temperature control that makes them energy efficient and power saving.
- 2. The high torque motor drive system is designed for long lasting durability.
- 3. The seven and nine roller grills have separate controls for front and back rollers.
- 4. The bottom is made of stainless steel with an extractable stainless steel oil plate which keeps the machine easy to clean.

Parts Identification



Technical Specifications

Model	Dimension (inches)	Voltage (V)	Power (W)	Hot Dog Quantity
RG1824	$22^{7/8}$ " x $15^{3/4}$ " x $8^{3/4}$ "	120V/60HZ	750	24



Important Safeguards

- 1. Thoroughly read this instruction manual prior to first use.
- 2. Do not submerge unit and/or cord in water or any other liquids. Failure to heed this warning may result in electric shock, unit damage and/or bodily injury.
- 3. Close supervision is suggested when unit is in use, especially when children are present.
- 4. Check to ensure unit is in off position and unplugged when not in use or prior to cleaning. Allow grill to cool completely before cleaning.
- 5. Do not operate if the machine suffers serious damage or malfunctions. Contact dealer for repair or adjustment.
- 6. It is recommended that you use only manufacturer issued parts and accessories with this unit. Using unapproved parts may result in damage or injury.
- 7. Do not use outdoors.
- 8. Do not let cord hang over the edge of table or counter. Do not let it touch any hot surfaces.
- 9. Do not place appliance on or near gas or electric burners or heated ovens.
- 10. Securely insert plug into outlet. When unplugging, be sure to remove plug only. Never pull by the power cord.

Installation

- 1. To avoid equipment or electrical damage, make certain that the nameplate voltage is the same as the outlet voltage.
- 2. Electrical and grounding connections must be in compliance with the applicable portions of the electrical code.
- 3. Prior to first use, it is recommended that you clean the rollers of the machine with a cotton or wipe-pad.

Operation Guide

- 1. Evenly place unfrozen hot dogs on the rollers.
- 2. The left knob controls the front rollers and the right knob controls the back rollers. Both rows may be used for operation during high volume use.
- 3. Turn the roller switch on the control plate to "ON". This switch controls the rotation of the rollers.
- 4. Turn the knob to the desired heat level. After 40 minutes of heating the hot dogs, turn the temperature control knob lower to continuously keep warm.
- 5. The heating duration depends on the hot dogs' quality. Please adjust as needed or required. Average heating duration is 40 minutes, but may vary.



Cleaning Instructions

- 1. To avoid electric shock or scalding, unplug the power cord and allow the unit to cool before cleaning.
- 2. Do not submerge the hot dog grill in water or directly apply liquids to clean unit.
- 3. When cleaning the rollers, wipe from the end of the rollers to the center. This will reduce grease and particles from getting into the bearings. Proper cleaning may extend the life of the unit and extend the period between routine maintenances.
- 4. For product with high fat or sugar content, clean the rollers every 3-4 hours.
- 5. Remove the hot dogs from the rollers when wiping. Do not touch the heated rollers directly as this may result in burning or scalding.
- Do not clean roller tubes with abrasive cleaners or scouring pads because this may damage the rollers surface and the particles may get into the bearing.



Attack tough grease, oil, and carbon with this ready to use carbonizer and degreaser. Its unique formula is designed to clean ovens, grills, hoods and a wide variety of other surfaces.

Suggestions

- 1. Hot dogs must be fully unfrozen.
- 2. Do not leave hot dogs on the grill too long to ensure the best results. If warming for more than four hours, the hot dogs may become thick and hard.

Limited Warranty

All equipment, which is sold under Avantco trademark and used for commercial purpose is warranted against defects in materials and workmanship. The warranty runs for six months from the date of original installation and is for the benefit of the original purchaser only. All other Warranties, Expressed or Implied, Statutory or Otherwise, including Without Limitation any implied Warranty of Merchantability or Fitness for Purposes are excluded. The Seller shall in no event be liable for direct, indirect or consequential damages in connection with Avantco commercial products.


This warranty is not effective if damage occurs because of accident, carelessness, improper installation, lack of proper set—up, supervision when required or if the equipment is installed or operated in any manner contrary to the installation and operating instructions. Work performed by unauthorized personnel or unauthorized service agencies voids this Warranty.

This warranty does not apply to, and Avantco is not responsible for, any warranty claims made on products sold or used outside of the United States.




Circuit Diagram

RG1824





Parts Diagram





Parts List

No.	Name	Specification	Qty. (PCS)
1	Bolt	M4 x 8,Galvanized	6
2	Bolt	M5 x 16,stainless steel	6
3	Foot	Rubber	6
4	Glass cotton	Glass cotton	2
5	Housing	Stainless steel	1
6	Round head screw	M4 x 8,Stainless steel	4
7	Side board	Stainless steel	1
8	Insulated plate		2
9	Heating element supporter	Aluminum Plated	1
10	Heating element supporter	Aluminum Plated	1
11	Coil	Plastic	1
12	Power cord with plug	16#cord, NEMA 5-15 PLUG	1
13	Tube	1 ^{1/} 2" x ^{1/} 4"	18
14	Tube pin	1 ^{1/} 2" x ^{1/} 8"	18
15	Tube with wheel	1 ^{1/} 8" x 19 ^{3/} 4"	9
16	Heating element	120V 80W	9
17	Heating element fixer	Stainless steel	1
18	Bolt	M4 x 8,Galvanized	9
19	Side board	Stainless steel	1
20	Chain	3.2mm a	1
21	Bolt	M4 x 8,Galvanized	4
22	Motor wheel		1
23	Motor	120V,5.6round/min	1
24	Mesh supporter	Plastic	8
25	Indication light	16A,250V(yellow)	2
26	Switch	41	2
27	Thermostat	EGO	2
28	Bolt	M4 x 6, Galvanized	4
29	On/off		1
30	Oil Pot		1