



Electric Rice Cooker/Warmers

(Includes Standard Rice Cup & 7" Rice Paddle)

Models:

177GRCB30 • 30 Cup (15 Cup Raw)

08/2024


Read and save these instructions for future reference. Indoor use only.

Index

Specifications	2
Safety	3
Cautions	4
Parts Identification	4
Operation	5
Using an Extension Cord	6
Cleaning	6
Unique Features	7
Suggestions	7

Specifications

Model	177GRCB30
Voltage	120V
Wattage	950W
Capacity (Raw)	15 Cups
Capacity (Cooked)	30 Cups
Weight	12 lb.
Width	13½"
Depth	12"
Height	11¼"



NEMA 5-15P

Safety


1. Read all instructions carefully before using the appliance for the first time.
2. Do not touch hot surfaces. Use handles.
3. To prevent electric hazards, do not immerse cord, plug, or rice cooker heating plate in water or other liquid.
4. Close supervision is necessary when children are present.
5. Before plugging in power cord, ensure voltage rating of outlet is suitable for the equipment.
6. Unplug appliance from wall outlet when not in use and before cleaning. Allow appliance to cool completely before putting on or taking off pot.
7. Do not operate appliance if cord has been damaged, or if appliance malfunctions or suffers serious damage.
8. Never put water or any liquid into the outer pot. Water should be placed only in the inner pot.
9. Do not heat cooking pot on any other stove.
10. Never plug in the power cord without the inner pot inside the cooker.
11. Only use the inner pot provided.
12. Do not let cord hang over edge of table or counter or allow it to touch hot surfaces.
13. Do not place appliance on or near gas or electric burner or in heated oven.
14. Use extreme caution when moving appliances containing hot oil or other hot liquids.
15. Always plug cord into a wall outlet. To disconnect, remove by plug, not cord.
16. Always place the unit on a flat, level surface.
17. Rice cooker should be stored and operated away from high temperatures.
18. Do not block the steam vent on the top of the lid.
19. Do not connect or disconnect the power cord with wet hands.
20. Never place the unit into your refrigerator or freezer.
21. Do not use this appliance for anything other than its intended use.
22. Do not use abrasive sponges and scrubbers that could scratch surface.
23. **CAUTION:** Risk of fire or burn hazard. Do not store combustible material in container. To reduce the risk of electric shock, cook only in removable container. Risk of fire or electric shock. Only operate this appliance with the removable container in place.
24. **WARNING:** To reduce the risk of electric shock, do not remove or open bottom cover. No user-serviceable parts inside. Refer servicing to qualified personnel.
25. Any maintenance servicing should be performed by an authorized service representative.
26. Do not use this unit with an extension cord. Doing so can lead to damage to the rice cooker.

Cautions

1. Use only an electrical outlet with proper voltage.
2. Plug the unit directly into the electrical outlet. A short power cord is provided to reduce tripping hazards.
3. Do not dent the bottom of the inner pot, as it could affect warming.
4. If there is still some uncooked rice in the pot after the cooking cycle is complete, the unit may have been overloaded. Try putting in less rice next time.
5. Never fill the inner pot past the 15-cup water level measurement marking.

NOTE: Only use the inner pot provided. Using other brands may cause damage.


Parts Identification



Operation

NOTE: 1 cup of raw rice yields approximately 2 cups of cooked rice.

1. Rinse the raw rice in another container until the water runs clear.
2. Before putting anything in the inner pot, please read the Cautions section on page 4 carefully and observe the following instructions:
 - a. Wipe away any water outside the inner pot, then place the inner pot inside the cooker.
 - b. Turn the inner pot left and right to make sure the inner pot is placed above the heating plate properly.
3. Add in proper amount of raw rice to the pot:
Please use included measuring cup to measure the rice. One standard 6 oz. measuring cup is included with this cooker.
For example: For 10 cups of rice, add 10 measuring cups of raw rice to the pot.
NOTE: This measuring cup is the standard for rice cooker cups (6 oz.).
4. Add in the proper amount of water to the pot:
Fill the pot with water to the proper graduation mark or follow the 1 cup rice to 1 cup water rule (approximate) and adjust to taste.
For example: For 10 cups of rice, add water on top of 10 cups of rice up to the 10 cups graduation mark indicated on the water ruler on the inner pot.
NOTE: Water amount may need to be adjusted according to different types of rice.
Generally, 1 cup of rice requires 1 cup of water.
5. Place the lid on top of the pot.
6. Plug the power cord into the power outlet.
7. Push the cook switch down, you will see the "COOKING" indicator light turn on.
8. After the rice has finished cooking, the unit will automatically switch to its warming mode and the "KEEP WARM" indicator light will turn on. Wait 15 minutes before removing the cover to allow the steam to continue cooking the rice.
9. Stir rice before serving.
10. When finished, push the cook switch up to turn it off, and unplug the unit.



Cleaning

1. Unplug the unit and let it cool before cleaning.
2. DO NOT immerse any part of the outer body into water. Clean the outside of the rice cooker with a damp cloth, then wipe dry with a dry cloth.
3. Clean the inner pot with a rubber or foam sponge. **Do not use a rough cleaning tool, as it will damage the nonstick coating. If necessary, soak in warm, soapy water then gently clean the bottom of the cooking pot with a dish cloth.**
NOTE: Be careful not to press down too hard or drop anything on the bottom of the cooking pot, as this can cause warping and inhibit the proper functioning of the rice cooker.
4. Remove and empty the water reservoir.
5. Clean the heater pieces with a damp cloth, then wipe dry with a dry cloth.
6. Ensure the entire unit is dry before storing.

Unique Features

EASY ONE-TOUCH OPERATION: A simple ON/OFF control switch assures ease of operation.

AUTOMATIC SHUT-OFF AND WARMING FUNCTIONS: When the rice is cooked, the rice cooker shuts off the switches automatically to the warm function.

Suggestions

For Best Results:

1. When washing rice, use warm water and wash lightly. Do not scrub with force. Pour out the water quickly, and repeat the process 2 to 3 times until the rice is clear.
2. After the rice is washed, it should be immersed in water for 30-60 minutes before cooking.
3. The amount of water needed will depend on the type and quality of the rice.
Generally, 1 cup of rice requires 1 cup of water.
4. For best results, do not warm rice for more than 12 hours.