



60 Cup (30 Cup Raw) Electric Rice Cooker

Model: 177RC60

05/2023

Please read and save these instructions for future reference. Indoor use only.

NOTE: Save these instructions for future reference.

Index

Specifications	2
Keep Warm	2
Safeguards	3
Parts List	4
Safe Usage	5
Maintenance	6
Unique Features	7
Cleaning	7
Troubleshooting	8

Specifications



Model No	177RC60
Power Rating	1550W
Voltage	120V ~ / 60Hz
Capacity	60 cups / 30 cups raw
Weight	24.4 lb.
Dimensions	18"D x 137/8"H

Keep Warm


1. This rice cooker will automatically keep rice warm provided the power cord remains plugged in.
2. For safety reasons, always disconnect the power cord from the wall outlet when the cooker is not being used and the warm function is not desired, or when removing the inner cook pot from the outer pot.
3. Do not warm up more than 12 hours. Try to eat the rice within 12 hours.
4. Store leftover rice in the refrigerator and re-heat in the rice cooker by adding some water to the rice to cook.
5. To prevent electrical shock hazards, do not immerse the warmer, except the inner pan and inner lid, into water nor any other liquid.

Important Safeguards

1. Read all instructions carefully before using the appliance for the first time.
2. Do not use outdoors: commercial and indoor use only.
3. Do not immerse in water.
4. CAUTION: HOT SURFACE.
5. CAUTION: Risk of fire or burn hazard. Do not store near combustible material.
6. CAUTION: To reduce the risk of electric shock, cook only in removable container.
7. CAUTION: Risk of fire or electric shock. Only operate this appliance with the removable container in place.
8. To reduce the risk of electric shock, do not remove or open BOTTOM cover. No user-serviceable parts inside. Refer servicing to qualified personnel.
9. Rice cooker should be stored and operated away from high temperatures.
10. Do not block the steam vent on the top of the lid.
11. Before plugging in power cord, ensure voltage rating of outlet is suitable for the equipment.
12. Do not insert the plug cord into the socket without a pot in the rice cooker.
13. Do not heat cooking pot on any other stove.
14. Make sure the cover is properly locked when cooking.
15. Do not use abrasive sponges and scrubbers that could scratch surface.
16. Damage to power lines should be repaired by a certified technician.
17. Keep out of reach of children.
18. This product is not prepared for people with certain limitations (including children).

SAVE THESE INSTRUCTIONS

Parts Identification



Cautions

1. Use only an electrical outlet with proper voltage.
2. Do not share the electrical outlet with other kitchen appliances while using your rice cooker.
3. If there is still some uncooked rice in the pot after the cooking cycle is complete, the unit may have been overloaded. Try putting in less rice next time.
4. Never fill the inner pot past the 30 cup measurement marking.

NOTE: Only use the inner pot provided. Using other brands may cause damage and void the warranty.

How to Use

1. Please use measuring cup to measure the rice. One big measuring cup attached in this cooker may cook 10 bowls of well done rice. Note: this measuring cup is five times the size of a general rice cooker measuring cup. One big cup equals five regular cups.
2. Please use another container to wash the raw rice until water is clear.
3. This unit can cook a maximum of 10 lb. of rice with 15 lb. of water. Choose either one of the following two ways to add in proper amount of water:
 - a. Make use of the water graduation marks of the inner pot.
For example: for 20 cups rice (4 measuring cups of this cooker), add the water to 20 cup graduation marks indicated on the water ruler. For 30 cups rice (6 measuring cups), add the water to 30 cup marks.
 - b. Make use of the attached measuring cup to add equal amounts of water and rice.
For example: Add 5 cups of raw rice to 5 cups of water.

NOTE: Water amount will be adjusted according to different kinds of rice.

4. Before putting in the inner pot, please read the cautions carefully and observe the following instructions:
 - a. Dry the water inside/outside the cooker.
 - b. Wipe away the water outside the inner pot, then place the inner pot inside the cooker.
 - c. Turn the inner pot left and right to make sure the inner pot is placed above the heating plate properly.
5. Use the cover to cover the cooker. Make sure the push button is actually pressed.

How to Use (Continued)

6. Plug the power cord into the power outlet.
7. Press the cook switch down. You will see the “cook” indicator light go on.
8. After the rice has finished cooking, the unit will automatically switch to its warming mode.
Wait 15 minutes before removing the cover to allow the steam to continue cooking the rice.
9. Stir rice before serving.
10. When finished, turn the switch to OFF and unplug the unit.

Using an Extension Cord

A short power cord is provided to reduce tripping hazards. Longer extension cords are available and may be used if care is exercised in their use. If an extension cord is used, please follow these instructions:

1. The marked electrical rating of the extension cord should be equal to or greater than the cooker's (15A or over).
2. Only use an extension cord that is grounded (for countries where applicable).
3. Arrange extension cord so that it does not hang from cooking surface, counter, or table.
4. Place the extension cord where it cannot be pulled on by children or tripped over accidentally.

Maintenance Guide

1. Unplug the plug from the wall socket before cleaning. Wait until unit is cold to clean.
2. Clean the outside of the rice cooker with a damp cloth. And then clean the outside of the rice cooker with a dry cloth again.
3. Clean the inner pot with a rubber or foam sponge. **Do not use a rough cleaning tool as it will damage the nonstick coating.**
4. Unplug the water reservoir and dispose of the water contained therein.
5. Clean the heater pieces with a damp cloth. And then clean the heater pieces with a dry cloth again.

Unique Features

EASY ONE TOUCH OPERATION: A simple push-button/ON-OFF control switch assures ease of operation.

AUTOMATIC SHUT-OFF AND WARMING FUNCTIONS: When the rice is cooked, the rice cooker shuts off the switches automatically to the warm function.

LARGE SERVING QUANTITY: With the measuring cup attached in this cooker, 6 cups may cook 60 bowls of rice.

Cleaning

1. Un-plug the power cord from the wall before cleaning.
2. DO NOT immerse any part of the outer body into water. Wipe clean with a dish cloth.
3. To clean the cooking pot, soak in hot sudsy water then gently clean the bottom of the cooking pot with a dish cloth. BE CAREFUL not to press down too hard, or drop anything on the bottom of the cooking pot, as this can cause warping and inhibit the proper functioning of the rice cooker.
4. Wipe the cooker body and cooking pot dry before storing.

Suggestions

For Best Results:

1. When washing rice, use warm water and wash lightly. Do not scrub with force. Pour out the water quickly, and repeat the process 2 to 3 times until the rice is clear.
2. After the rice is washed, it should be immersed in water for 30-60 minutes before cooking.
3. The amount of water needed will depend on the age and quality of the rice. Generally, 1 cup of rice requires 1 cup of water.

Troubleshooting

Issue	Solution
Rice is not fully cooked	Adjust the ratio. Refer to rice packaging or recipe's instructions.
	Turn off and unplug unit, allow to fully cool, then remove pieces of rice with a dry cloth.
	Replace the inner tank or heating plate.
	Ensure the top cover is properly secured.
	Press the "Cook" button again.
Unit does not turn on	Check multiple outlets for a power connection. Ensure your outlet is properly wired for the electrical specifications of this unit.
Rice is overcooked	After the rice is cooked and has entered the "Keep Warm" stage, do not press the "Cook" button again.
	Turn off and unplug unit, allow to fully cool, then remove pieces of rice with a dry cloth.
Air leaks from the lid during cooking	Ensure the top cover is properly secured.
	Replace the inner pot.
Dead upon arrival	Trying plugging into multiple outlets. If this does not resolve the issue and your unit is under warranty reach out to customer service.
Powers on, but will not get hot	Make sure the outer bottom of the pot and the inner plate of the drum are cleaned. All of these areas must be clear from all liquid, dirt, or rice to fit flush together and work properly.
Switches quickly from cooking to warming without cooking	If the unit switches from cooking to warming immediately, or after few minutes, ensure that you are not overusing the unit. The unit must have time to cool down completely before another cook cycle.
	Make sure the outer bottom of the pot and the inner plate of the drum are clean.
Rice is not cooking	Ensure the unit has a rice cooking function, not just a rice warming function.
	Wash and soak the rice for at least 15 minutes before attempting to cook (30-60 minutes for best results).
	After switching from cooking to warming mode, the rice should be left to stand in the cooker with the lid on for 15 minutes before serving.