


User Manual

Model: 177SDM400



Before operating this unit, please read manual completely.

Important Safety Instructions

1. This appliance is not intended for use by anyone under the age of 18.
2. To avoid electrical hazards, do not place the drink mixer in or near water or other liquid.
3. Do not place hands or any objects near moving parts while the drink mixer is powered on.
4. Always make sure the drink mixer is unplugged before cleaning or removing any parts.
5. Do not use outdoors.
6. Power cord should be tucked away safely and not touching any hot surfaces.
7. Never immerse your drink mixer into water or other liquids.
Clean the exterior using a damp cloth.

Using Your New Drink Mixer

1. Remove the equipment from the packaging and inspect for any damages.
2. Prior to use, clean the drink mixer using a damp cloth and the soap of your choice such as Noble Chemical "Strike" All Purpose Cleaner and Degreaser.
3. After cleaning, set the drink mixer on the counter near an outlet and plug it in.
4. Prepare your ingredients to mix inside of the malt cup included with the drink mixer.
5. When ready, turn the mixer on using the on/off switch.
6. Select desired speed.
7. Place cup against the activator switch located near the top of the spindle on the unit. The rolled edge of the cup can rest on the ledge to hold the cup in place during mixing.
8. Allow the spindle to mix the ingredients until desired end product has been achieved. Mixer will turn off when cup is pulled away from the activator switch.
9. When finished using the drink mixer, switch off and unplug the unit.

Cleaning Instructions

1. For an easy cleaning option, consider the San Jamar KLC28C Commercial Sanitizing Kleen-Cup. This product helps to ensure the spindle remains clean and your drink mixer is able to operate efficiently.
2. Power off and unplug the drink mixer.
3. Prepare your desired sanitizing solution and apply to a cloth. Begin at the top of the drink mixer working your way down. DO NOT let water/sanitizer enter the vents located on the back of the unit. For easy sanitizing, try Noble Chemical's QuikSan Ready to Use Sanitizer and Disinfectant. Simply spray on and allow QuikSan to air dry in between uses.
4. Pay special attention to cleaning the spindle. It is a good idea to use a small brush to remove debris from the agitator.
5. Dry the unit completely before using again.

Warranty Information

90 DAY REPLACEMENT WARRANTY

(Valid from date of purchase)

- This warranty is not effective if damage occurs because of an accident, carelessness, improper installation, lack of proper set-up, supervision when required or if the equipment is installed or operated in any manner contrary to the installation and operating instructions.
- Work performed by unauthorized personnel or unauthorized service agencies voids this warranty.
- This warranty does not apply to any warranty claims made on products sold or used outside of the United States.

TO AVOID DAMAGE, DO NOT LIFT MIXER BY THE SHAFT!

Mixer Diagram

